MODEL 1321/1421/1521/1721 DUAL AUGER GRAIN CARTS OPERATOR MANUAL

M0316-01 Rev. 4/25

This manual is applicable to: 2022 Production and on

Record model number and serial number of your grain cart along with date purchased:

Model Number_____

Serial Number _____

Date Purchased_____

SERIAL NUMBER

Record your serial number and purchase date above for quick reference.

The serial number provides important information about your grain cart and is required to obtain correct replacement parts. Always provide grain cart model and serial number to your Kinze Dealer when ordering parts or anytime correspondence is made with Kinze Manufacturing, Inc.



Serial number plate location

Kinze[®] and the Kinze[®] logo are registered trademarks of Kinze Manufacturing, Inc.

Shur-Co[®], LLC is a registered trademark of Shur-Co.

Microsoft® Excel®, and Internet Explorer® are registered trademarks of Microsoft Coroporation.

Grain Tracker™ is a trademark of Digi-Star LLC

All other tradmarks are the property of their respective owners.

Page intentionally blank.

1321-1421-1521-1721 Grain Cart PREDELIVERY/DELIVERY CHECKLIST

TO THE DEALER

Predelivery service includes assembly, lubrication, adjustment and test. This service ensures cart is delivered to retail customer/end user ready for field use.

PREDELIVERY CHECKLIST

Use this checklist to inspect cart after it is completely assembled. Check off each item as it is found satisfactory or after proper adjustment is made.

□ Wheel nuts torqued to 350 ft-lb (474 N-m).

□ Tires inflated to specified air pressure. (If Applicable)

□ All grease fittings lubricated and gearbox oil level checked.

□ All safety decals and SMV sign are correctly located and legible. Replace if damaged.

□ SMV decal is in place and shipping cover removed.

Safety/warning lights working properly.

□ Test run augers. Do not operate tractor PTO above 750 PTO RPM with augers empty.

Check driveline. See "Driveline Inspection" in Lubrication and Maintenance section.

Check track alignment. See "Track Alignment" in Maintenance section. (If Applicable)

□ Safety screens over horizontal auger are in place and properly secured.

Auxiliary safety chains are properly installed and hardware torqued to specification.

Deaint all parts scratched in shipment.

This wagon has been thoroughly checked and to the best of my knowledge is ready for delivery to the customer.

(Signature Of Set-Up Person/Dealer Name/Date)

OWNER REGISTER

Name	Delivery Date
Street Address	Model NoSerial No
City, State/Province	Dealer Name
ZIP/Postal Code	Dealer No.



DELIVERY CHECKLIST

Check off each item as it is fully explained to retail customer/end user when grain cart is delivered.

- Durability and longevity is dependent on regular maintenance as directed in Operator Manual.
- Tell retail customer/end user about all safety precautions that must be observed while using this cart.
- Advise retail customer/end user of specified tractor requirement for use with this cart.
- □ Along with retail customer/end user check reflective decals and SMV sign are clearly visible with cart attached to tractor. Check safety/warning lights are in working condition. Tell retail customer/end user to check and follow federal, state/provincial, and local regulations before towing on a road or highway.
- Along retail customer/end user check hitch height when attached to tractor is sufficient to prevent severe bends in PTO U-joint angles. Check PTO is correct length for making turns and operating on uneven terrain.
- Give Operator and Parts Manuals to retail customer/end user and explain all operating adjustments.

Complete Warranty And Delivery Report form.

To the best of my knowledge this machine has been delivered ready for field use and customer has been fully informed as to proper care and operation.

(Signature Of Delivery Person/Dealer Name/Date)

AFTER DELIVERY CHECKLIST

Suggested items to check during first season of use:

- Check cart performance with retail customer/end user.
- Review with retail customer/end user importance of proper maintenance and adherence with all safety precautions.
- Check for parts that may need to be adjusted or replaced.
- Retorque all wheel nuts to 350 ft-lb (474 N-m).
- Check track belt alignment (if applicable).
- □ Safety shields and screens are in place.
- Safety and reflective decals, and SMV sign are correctly located and decals are legible. Replace if damaged or missing.
- Check safety/warning lights are properly installed and working properly.
- Check recommended lubrication procedures are being followed.

(Signature Of Follow-Up Person/Dealer Name/Date)

Tear Along Perforation

All registrations must be submitted online at "<u>business.kinze.com</u>" within 5 business days of delivery. Retain a copy of this form for auditing purposes.



OVERVIEW

To the Owner1-1
Warranty1-3
General Information1-3
Introduction1-3
General Safety Rules1-8
Safety Instructions, Signs, and Decals1-9
Safety Signs And Decals1-10
Safety Instructions, Signs, and Decals1-10

OPERATION

Machine Preparation
Tractor Requirements2-1
Tractor Preparation and Hookup
Handheld Remote Control
Cart Operation
PTO Torque Limiting/Overrunning Clutch Protection 2-8
Belt Engagement Indicator
Hydraulic Flow Gate
Auger Inspection Cover
Grain Tank Clean Out Sweep
Vertical Auger Work Light
Manual and Electric Roll Tarp
Roll Tarp Remote Control Troubleshooting
Track System Components - Models 1321/1421/15212-17
Track Transport Speeds - ALL Track Models
Track System Minimum Turning Radius Limitations - All Track Models
Track System Break-In Procedures - All Track Models 2-19
Track System Operational Guidelines - All Track Models 2-20
Electronic Scale - GT 400
Electronic Scale - GT 560
Scale-Tec POINT
Auxiliary Scale Display
Electronic Scale - GT 560 AutoLog2-26
Electronic Scale Troubleshooting
Electronic Scale Troubleshooting
POINT ISOBUS Troubleshooting
Enable ISOBUS PTO and GPS Detection For Use With REAP2-31
Track System Troubleshooting

LUBRICATION AND MAINTENANCE

Splines	3-1
Wheel Bearings	3-1
Track Endwheel and Midwheel Bearings -	21
	J-1

Horizontal Auger Bearings
Drive Belts and Pulleys. 3-2 Gearbox Oil Level. 3-2 PTO Shaft Coupling 3-2 Grease Fittings 3-3 Track System Maintenance 3-8 Check Track Alignment - 1321/1421/1521 Only 3-10 Track System Inspection - All Track Models 3-12
Gearbox Oil Level. .3-2 PTO Shaft Coupling .3-2 Grease Fittings .3-3 Track System Maintenance .3-8 Check Track Alignment - 1321/1421/1521 Only .3-10 Track Alignment procedure - 1321/1421/1521 Only .3-11 Track System Inspection - All Track Models .3-12
PTO Shaft Coupling
Grease Fittings
Track System Maintenance
Check Track Alignment - 1321/1421/1521 Only
Track Alignment procedure - 1321/1421/1521 Only3-11 Track System Inspection - All Track Models
Track System Inspection - All Track Models
Track Removal - 1321/1421/1521 Only
Track Installation - 1321/1421/1521 Only
Mid-Roller Wheel Seal and Bearing Removal and Installation
Mid-Roller Wheel Seal and Bearing Installation
Metal Face Seal Preparation and Installation
Top Roller Wheel and Seal Removal
Track Tension - Model 1721 Only
Track Alignment - Model 1721 Only
Mounting Bolts and Hardware
Torque Values Chart - Plated Hardware
Vertical Auger Counter Balance Valves
Wheel Nuts
Tire Servicing
V-Belt Tension Adjustment and Alignment
V-Belt Replacement3-37
Driveline Inspection3-39
Upper Vertical Auger Replacement
Lower Vertical Auger Replacement
Horizontal Auger Replacement
Gearbox
Track Endwheel/Midwheel Bearing Replacement - Model 1721 Only3-43
Wheel Bearing Replacement
Preparation for Storage3-46
Hydraulic Control Schematic - Remote
Handheld Control Wiring Diagram
Wiring Diagram3-50
Electronic Scale
Control Cable Extension (P/N: A16354)
Scale Harness Extension Cable (P/N: 10565201) 3-52
Junction Box 30' Cable (P/N: R1431)





This page intentionally blank.

Kinze Manufacturing, Inc. thanks you for your patronage. We appreciate your confidence in Kinze farm machinery. Your Kinze grain cart has been carefully designed to provide dependable operation in return for your investment.

This manual has been prepared to aid you in the operation and maintenance of the grain cart. It should be considered a permanent part of the machine and remain with the machine when you sell it.

It is the responsibility of the user to read and understand the Operator Manual in regards to safety, operation, lubrication and maintenance before operation of this equipment. It is the user's responsibility to inspect and service the machine routinely as directed in the Operator Manual. We have attempted to cover all areas of safety, operation, lubrication and maintenance; however, there may be times when special care must be taken to fit your conditions.

Throughout this manual the symbol and the words **DANGER**, **WARNING**, and **CAUTION** are used to call attention to safety information that if not followed, will or could result in death or injury. **NOTICE** and **NOTE** are used to call your attention to important information. The definition of each of these terms follows:

DANGER	Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations, typically for machine components which, for functional purposes, cannot be guarded.
WARNING	Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.
CAUTION Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices	
NOTICE	Used to address safety practices not related to personal injury.

NOTE: Special point of information or machine adjustment instructions.





NOTE: Photos in this manual may be of prototype machines. Production machines may vary in appearance.

NOTE: Some photos and illustrations in this manual show optional attachments installed. Contact your Kinze Dealer for purchase of optional attachments.



4/22

Warranty

The Kinze Limited Warranty for your new machine is stated on the retail purchaser's copy of the Warranty And Delivery Receipt form. Additional copies of the Limited Warranty can be obtained through your Kinze Dealer.

Warranty, within the warranty period, is provided as part of Kinze's support program for registered Kinze products which have been operated and maintained as described in this manual. Evidence of equipment abuse or modification beyond original factory specifications will void the warranty. Normal maintenance, service and repair is not covered by Kinze warranty.

To register your Kinze product for warranty, a Warranty And Delivery Receipt form must be completed by the Kinze Dealer and signed by the retail purchaser, with copies to the Dealer, and to the retail purchaser. Registration must be completed and submitted to Kinze Manufacturing, Inc. within 5 business days of delivery of the Kinze product to the retail purchaser. Kinze Manufacturing, Inc. reserves the right to refuse warranty on serial numbered products which have not been properly registered.

If service or replacement of failed parts which are covered by the Limited Warranty are required, it is the user's responsibility to deliver the machine along with the retail purchaser's copy of the Warranty And Delivery Receipt to the Kinze Dealer for service. Kinze warranty does not include cost of travel time, mileage, hauling or labor. Any prior arrangement made between the Dealer and the retail purchaser in which the Dealer agrees to absorb all or part of this expense should be considered a courtesy to the retail purchaser.

Kinze warranty does not include cost of travel time, mileage, hauling, or labor.



General Information

Model 1421 Tracked Corner Auger Grain Cart w/optional electric roll tarp

Information used in these instructions was current at time of printing. However, due to Kinze's ongoing product improvement, production changes may cause your machine to appear slightly different in detail. Kinze Manufacturing, Inc. reserves the right to change specifications or design without notice and without incurring obligation to install the same on machines previously manufactured.

Right hand (R.H.) and left hand (L.H.), as used throughout this manual, are determined by facing direction machine travels in use unless otherwise stated.



Feature		
Heaped Capacity*	1300 Bushels (Track); 1250 Bushels (Flotation)	
Bushels/Minute - Max**	750 Bushels/minute	
Vertical Auger	Front fold, corner auger, computer balanced with concave double flighting with a thickened edge for increased durability; auger fold/extend shut-off valve 22" Diameter Flighting in 24" Diameter tube; ¼" edge; ¼6" Root flighting. 10° Auger Position control.	
Bearings - Vertical Auger	2"	
Horizontal Auger	20" Diameter Flighting in 22" Diameter tube; 1/4" edge; 7/16" Root flighting; cleanout doors	
Bearings - Horizontal Auger	6-bolt (rear) cast iron hub with tapered roller bearings and 4 lug spindle with 2 ball bearing flangette (front)	
Gearbox	Bevel and spur gear with 2:1 ratio	
Drive Belts	Two 4-band, multi-strand V-belts	
Drive Sheaves	8 groove - 8" drive/16" driven	
РТО	1¾"-20 spline, 1000 RPM PTO	
Kinze Tracks by Camso	36"W; 100" ground contact length; 7,214 Total Footprint (sq. in.); (2) 31 ¹ / ₂ " end wheels per track; (4) 13.77" mid wheels per track	
Spindle	Four - 4½	
Hub	two 20 bolt 13.189 bolt center cast ductile iron	
Tire	Flotation Tire: low ground pressure radial flotation IF1250/50R32 CFO (R1)	
Safety Chains	Two ½" grade 70 transport chains	
Adjustable Discharge Spout	Remotely 35° adjustable spout fitted with flexible discharge nozzle	
Hydraulic Flow Gate	Controls the rate of grain flowing to the horizontal auger for in-cab regulation of overall delivery rate	
Joystick Control	Intuitive, ergonomic and easy to control four different cart funcitons: spout tip, horizontal auger on/off, flow gate and auger tilt. Includes joystick, harness, solenoids and hydraulic hoses. One SCV remote to control flow gate, auger pivot, tip spout and horizontal auger engage/disengage. Second SCV remote required for auger fold.	
Manual Roll Tarp Package (Factory Installed)	Includes powder coated and galvanized end caps, aluminum side-mount latch plate, recessed tarp straps, adjustable tarp tension, stretch cord roll return, two ridge straps, long crank with retainer, (4) high-rise (12") tarp bows, and black 18oz. vinyl-coated fabric tarp. Electric roll tarp option available to purchase.	
Hydraulic Requirements	Minimum 300 HP; 2 SCVs with standard 2320 minimun system psi	

* Cart capacity and hitch weight are based on #2 corn at 15% moisture (56lb test weight). Cart capacity and hitch weight may vary based on crop type, grade, moisture and other environmental factors.

	Flotation Tire	Tracked
Weight - Empty	24,900 lbs (11294 kg)	31,000 lbs (14061 kg)
Hitch Weight - Empty	3,950 lbs (1792 kg)	3,950 lbs (1792 kg)
Hitch Weight - Loaded	6,280 lbs (2849 kg)	6,280 lbs (2849 kg)
Width - Overall	14'-0" (4.2M)	13'-0" (3.9M)
Height - Overall	11'-4" (3.45M)	11'-4" (3.45M)
Length - Overall	31'-7" (9.62M)	31'-7" (9.62M)



Feature	Specification
Heaped Capacity*	Flotation: 1350 bu.; Tracks: 1400 bu.
Bushels/Minute - Max*	750 Bushels/minute
Vertical Auger	Front fold, corner auger, computer balanced with concave double flighting with a thickened edge for increased durability; auger fold/extend shut-off valve 22" Diameter Flighting in 24" Diameter tube; ¼" edge; ¼s" Root flighting. 10° Auger Position control.
Bearings - Vertical Auger	2"
Horizontal Auger	20" Diameter Flighting in 22" Diameter tube; ¼" edge; ¼6" Root flighting; cleanout doors
Bearings - Horizontal Auger	6-bolt (rear) cast iron hub w/Tapered Roller Bearings and 4 lug spindle with 2 ball bearing flangette (front)
Gearbox	Bevel & spur gear with 2:1 ratio
Drive Belts	Two 4-band, multi-strand V-belts
Drive Sheaves	8 groove - 8" drive/16" driven
РТО	1¾" - 20 spline, 1000 RPM PTO
Kinze Tracks by Camso	36"W; 100" ground contact length; 7,214 Total Footprint (sq. in.); (2) 31 ¹ / ₂ " end wheels per track; (4) 13.77" mid wheels per track
Spindle	Two 6" high alloy
Hub	two 20 bolt 20.125 bolt center cast ductile iron or
Tire	Low ground pressure radial flotation IF1250/50R32 CFO (R1)
Safety Chains	Two Grade 70 40,500 lb. rated $\frac{1}{2}$ " chains certified to meet the requirements of ASAE S338.5
Adjustable Discharge Spout	Remotely 35° adjustable spout fitted with flexible discharge nozzle
Hydraulic Flow Gate	Controls the rate of grain flowing to the horizontal auger for in-cab regulation of overall delivery rate
Joystick Control	Intuitive, ergonomic and easy to control four different cart funcitons: spout tip, horizontal auger on/off, flow gate and auger tilt. Includes joystick, harness, solenoids and hydraulic hoses. One SCV remote to control flow gate, auger pivot, tip spout and horizontal auger engage/disengage. Second SCV remote required for auger fold.
Manual Roll Tarp Package (Factory Installed)	Includes powder coated and galvanized end caps, aluminum side-mount latch plate, recessed tarp straps, adjustable tarp tension, stretch cord roll return, two ridge straps, long crank with retainer, (5) high-rise (12") tarp bows, and black 18oz. vinyl-coated fabric tarp. Electric roll tarp option available to purchase.
Hydraulic Requirements	Minimum 350 HP; 2 SCV's with standard 2320 minimum system psi
Flotation Tire Size	Low ground pressure radial flotation IF1250/50R32 CFO (R1)

* Cart capacity and hitch weight are based on #2 corn at 15% moisture (56lb test weight). Cart capacity and hitch weight may vary based on crop type, grade, moisture and other environmental factors.

	Flotation Tire	Tracked
Weight - Empty	25,190 lbs (11296 kg)	31,470 lbs (14275 kg)
Hitch Weight - Empty	4,000 lbs (1814 kg)	4,000 lbs (1814 kg)
Hitch Weight - Loaded	6,540 lbs (2966 kg)	6,540 lbs (2966 kg)
Width - Overall	14'-0" (4.2M)	13'-0" (3.9M)
Height - Overall	10'-10" (3.9M)	10'-10" (3.9M)
Length - Overall	34'-11" (10.6M)	34'-11" (10.6M)



Feature	Specification
Heaped Capacity*	Flotation: 1450 bu.; Tracks: 1500 bu.
Bushels/Minute - Max**	750 Bushels/minute
Vertical Auger	Front fold, corner auger, computer balanced with concave double flighting with a thickened edge for increased durability; auger fold/extend shut-off valve 22" Diameter Flighting in 24" Diameter tube; ¼" edge; ¼₅" Root flighting. 10° Auger Position control.
Bearings - Vertical Auger	2"
Horizontal Auger	20" Diameter Flighting in 22" Diameter tube; ¼" edge; ¼6" Root flighting; cleanout doors
Bearings - Horizontal Auger	6-bolt (rear) cast iron hub w/Tapered Roller Bearings and 4 lug spindle with 2 ball bearing flangette (front)
Gearbox	Bevel and spur gear with 2:1 ratio
Drive Belts	Two 4-band, multi-strand V-belts
Drive Sheaves	8 groove - 8" drive/16" driven
РТО	1¾" - 20 spline, 1000 RPM PTO
Kinze Tracks by Camso	36"W; 100" ground contact length; 7,214 Total Footprint (sq. in.); (2) 31 ¹ / ₂ " end wheels per track; (4) 13.77" mid wheels per track
Spindle	Two 6" high alloy
Hub	two 20 bolt 20.125 bolt center cast ductile iron or
Tire	Flotation Tire: low ground pressure radial flotation IF1250/50R32 CFO (R1)
Safety Chains	two Grade 70 40,500 lb. rated $\frac{1}{2}$ " chains certified to meet the requirements of ASAE S338.5
Adjustable Discharge Spout	Remotely 35° adjustable spout fitted with flexible discharge nozzle
Hydraulic Flow Gate	Controls the rate of grain flowing to the horizontal auger for in-cab regulation of overall delivery rate
Joystick Control	Intuitive, ergonomic and easy to control four different cart funcitons: spout tip, horizontal auger on/off, flow gate and auger tilt. Includes joystick, harness, solenoids and hydraulic hoses. One SCV remote to control flow gate, auger pivot, tip spout and horizontal auger engage/disengage. Second SCV remote required for auger fold.
Manual Roll Tarp Package (Factory Installed)	Includes powder coated and galvanized end caps, aluminum side-mount latch plate, recessed tarp straps, adjustable tarp tension, stretch cord roll return, two ridge straps, long crank with retainer, (5) high-rise (12") tarp bows, and black 18oz. vinyl-coated fabric tarp. Electric roll tarp option available to purchase.
Hydraulic Requirements	Minimum 370 HP; 2 SCV's with standard 2320 minimum system psi

* Cart capacity and hitch weight are based on #2 corn at 15% moisture (56lb test weight). Cart capacity and hitch weight may vary based on crop type, grade, moisture and other environmental factors.

	Flotation Tire	Tracked
Weight - Empty	25,400 lbs (11521 kg)	31,680 lbs (14370 kg)
Hitch Weight - Empty	4,040 lbs (1832 kg)	4,040 lbs (1832 kg)
Hitch Weight - Loaded	6,600 lbs (2994 kg)	6,600 lbs (2994 kg)
Width - Overall	14'-0" (4.2M)	13'-0" (3.9M)
Length - Overall	34'-11" (10.6M)	34'-11" (10.6M)
Height - Overall	11'-4" (3.45M)	11'-4" (3.45M)



Feature	Specification		
Heaped Capacity*	1700 Bu		
Bushels/Minute - Max**	750 Bushels/minute		
Vertical Auger	Front fold, corner auger, computer balanced with concave double flighting with a thickened edge for increased durability; auger fold/extend shutoff valve 22" Diameter Flighting in 24" Diameter tube; ¼" edge; ¼6" Root flighting. 10° Auger Position c		
Bearings - Vertical Auger	2"		
Horizontal Auger	20" Diameter Flighting in 22" Diameter tube; ¼" edge; ¼6" Root flighting; cleanout doors		
Bearings - Horizontal Auger	6-bolt(rear) cast iron hub w/Tapered Roller Bearings and 4 lug spindle with 2 ball bearing flangette (front)		
Gearbox	Bevel and spur gear with 2:1 ratio.		
Drive Belts	Two 4-band, multi-strand V-belts.		
Drive Sheaves	8 Groove - 8" Drive/16" Driven		
РТО	1¾" - 20 spline, 1000 RPM PTO		
Kinze Tracks	36"W; 108" ground contact length; 7,776 Total Footprint (sq. in.); (2) 31 ¹ / ₂ " end wheels per track; 8 mid wheels per track		
Track-End Wheels (Per Track)	(2) cast iron-segmented 361/2" diameter		
Track-Mid Wheels (Per Track)	(4) - 16" steel		
Safety Chains	Two ½" 40,500 lbs rated, grade 70, certified to ASAE S338.5.		
Adjustable Discharge Spout	Remotely 35° adjustable spout fitted with flexible discharge nozzle		
Hydraulic Flow Gate	Controls the rate of grain flowing to the horizontal auger for in-cab regulation of overall delivery rate		
Joystick Control	Intuitive, ergonomic and easy to control four different cart funcitons: spout tip, horizontal auger on/off, flow gate and auger tilt. Includes joystick, harness, solenoids and hydraulic hoses. One SCV remote to control flow gate, auger pivot, tip spout and horizontal auger engage/disengage. Second SCV remote required for auger fold.		
Manual Roll Tarp Package (Factory Installed)	Includes powder coated and galvanized end caps, aluminum side-mount latch plate, recessed tarp straps, adjustable tarp tension, stretch cord roll return, two ridge straps, long crank with retainer, (5) high-rise (12") tarp bows, and black 18oz. vinyl-coated fabric tarp. Electric roll tarp option available to purchase.		
Hydraulic Requirements	Minimum 450 HP; 2 SCV's with standard 2320 minimum system psi		

* Cart capacity and hitch weight are based on #2 corn at 15% moisture (56lb test weight). Cart capacity and hitch weight may vary based on crop type, grade, moisture and other environmental factors.

	Tracked
Weight - Empty	35,180 lbs (15957 kg)
Hitch Weight - Empty	5,250 lbs (2381 kg)
Hitch Weight - Loaded	7,380 lbs (3347 kg)
Width - Overall	13'-0" (3.9M)
Length - Overall	38'-10" (11.8M)
Height - Overall	11'-4" (3.45M)



1. Read and understand instructions provided in this manual and warning labels. Review these instructions frequently!

2. This machine is designed and built with your safety in mind. Do not make any alterations or changes to this machine. Any alteration to design or construction may create safety hazards.

3. A large portion of farm accidents happen from fatigue or carelessness. Safe and careful operation of tractor and grain cart will help prevent accidents.

4. Never allow cart to be operated by anyone unfamiliar with operation of all functions of the unit. Operators must read and thoroughly understand all instructions given in this manual before operating or working on equipment.

5. Be aware of bystanders, particularly children! Always look around to make sure it is safe to start tow vehicle engine or move grain cart. This is particularly important with higher noise levels and quiet cabs, as you may not hear people shouting.

6. Make sure cart weight does not exceed towing capacity of tractor, or bridge and road limits. This is critical to maintain safe control and prevent death or injury, or property and equipment damage.

7. Never ride or allow others to ride on cart

8. Store cart in an area away from human activity. DO NOT permit children to play on or around stored unit.

9. Keep hands, feet, and clothing away from moving parts. Do not wear loose-fitting clothing which may catch in moving parts.

10. Always wear protective clothing, shoes, gloves, and hearing and eye protection applicable for the situation.

11. Do not allow anyone to stand between tongue or hitch and towing vehicle when backing up to cart.

13. Prevent electrocution, other injuries, or property and equipment damage. Watch for obstructions such as wires, tree limbs, etc. when operating machine. Be aware of clearances during turns and when folding/unfolding grain chute.

14. Pick levelest possible route when transporting across fields.

15. Never operate grain cart without PTO driveline guards, tractor master shield and implement shields in place. Make certain PTO driveline guards turn freely and are properly attached.

16. Make sure parked machine is on a hard, level surface. Wheel chocks may be needed to prevent unit from rolling.

17. Follow all federal, state/provincial and local regulations when towing farm equipment on a public highway. Use safety chain (not an elastic or nylon/ plastic tow strap) to retain connection between towing and towed machines in the event of primary attaching system separation.

18. Make sure all safety/warning lights, SMV sign, and reflective decals are in place and working properly before transporting machine on public roads.

19. Tow only with farm tractor of a minimum 90 HP. Allow for unit length when making turns.

20. Track carts should be limited to road use only when empty and speed to less than 15 MPH.

21. Maintain field drive speeds that are appropriate to the load condition and field condition.

22. Reduce speed prior to turns to avoid the risk of overturning. Avoid sudden uphill turns on steep slopes. Always drive at a safe speed relative to local conditions and ensure your speed is slow enough for a safe emergency stop.

23. Always keep the tractor in gear to provide engine braking when going downhill. Do not coast.

24. Always disengage PTO, shutoff tractor engine and remove the ignition key before leaving tractor seat, lubricating or working on grain cart, or when cleaning out debris.

25. Always make sure U-joint yokes are securely locked on tractor and implement shaft before operating cart.

26. Be especially observant of the operating area and terrain. Watch for holes, rocks or other hidden hazards. Always inspect area before operation. DO NOT operate near edge of drop-offs or banks, or on steep slopes as overturn may result. Operate up and down (not across) intermediate slopes. Avoid sudden starts and stops. Be extra careful when working on inclines.

27. Never step across any driveline. Do not attach drivelines with bolts or pins longer than recommended. Never operate cart with damaged PTO driveline guards.



Following are some common hazard warnings associated with this equipment. Pay close attention to all safety, operating, and maintenance information in this manual and decals applied to your equipment.



Safety Signs And Decals



Safety signs and decals are placed on the machine to warn of hazards and provide important operating and maintenance instructions. Information on these signs are for your personal safety and the safety of those around you. FOLLOW ALL SAFETY INSTRUCTIONS!

- Keep signs clean so they can be easily seen. Wash with soap and water or cleaning solution as required.
- Replace safety signs if damaged, painted over, or missing.
- Check reflective decals and SMV sign periodically. Replace if they show any loss of reflective properties.
- When replacing decals, clean machine surface thoroughly with soap and water or cleaning solution to remove all dirt and grease.

NOTE: Safety sign and decal locations are shown in the Parts Manual for this machine.

NOTE: Style and locations of SMV sign, reflective decals, and safety/warning lights conform to ANSI/ASABE S279.14 JUL 2008 and ANSI/ASABE S276.6 JAN 2005.



MACHINE PREPARATION

Lubricate grain cart per lubrication information in this manual prior to initial operation and at prescribed intervals. Make sure all tires are properly inflated or track tension is properly adjusted before each use. Check drive V-belts for proper tension and alignment. Torque all wheel lug nuts to specified torque.

TRACTOR REQUIREMENTS

Consult your dealer for information on horsepower requirements and tractor compatibility. Two remote SCV's are required for remote joystick operation and five SCV's are required for standard cab operation . A 12 volt DC electrical system is required on all sizes to operate safety/warning lights, auger-mounted work light, optional electronic scale system, or electronic roll tarp.

TRACTOR PREPARATION AND HOOKUP

1. Slide tractor drawbar in as far as possible and still allow PTO shaft to have sufficient clearance to prevent damage to driveline components when making sharp turns and operating over uneven ground.



Avoid clevis hitch interference





PTO shaft positioned for tractor hookup



2. Position PTO in upright position and secure with PTO holder (chain) until parking jack is raised.



Operation



Jack handle stowed



Jack handle installed

- 3. Remove hairpin clip and jack handle from storage location.
- 4. Install jack handle on jack shaft and raise cart.



- 5. Connect cart to tractor hitch. Use a high quality hitch pin of sufficient length and strength and secure pin with a locking device.
- 6. Raise jack. Return jack handle to storage location and install hairpin clip.



Safety chains

- 7. Attach cart PTO connecting yoke to tractor PTO shaft. Spring loaded yoke pin must engage groove in tractor PTO shaft. Slip tube grease fitting must be visible through hole of outer tube.
- 8. Transport safety chain must be used to ensure connection is retained between cart and tractor in the event of a hitch pin/drawbar failure. Torque attaching hardware to 840 ft-lb (1138 N-m).



WARNING	Pressurized hydraulic fluid can penetrate body tissue and result in death, serious infection, or other injuries. Fluid injected under skin must be IMMEDIATELY removed by a surgeon familiar with this type of injury. Make sure connections are tight and hoses and fittings are not damaged before applying system pressure. Leaks can be invisible. Keep away from suspected leaks. Relieve pressure before searching for leaks or performing any system maintenance.
NOTICE	Wipe hose ends to remove any dirt before connecting couplers to tractor

Wipe hose ends to remove any dirt before connecting couplers to tractor parts or contamination may cause equipment failure.

9. Connect hydraulic hoses to tractor.

GRAIN CART TO TRACTOR HYDRAULIC CONNECTIONS			
Color	Machine Function	Hose Size	Function
Red	Augor	1⁄4"	Extend
Red	Auger	1⁄4"	Retract
Blue	Auvilian	³ ⁄8"	On
Blue	Auxillary	3⁄8"	Off



- 10. Connect seven terminal breakaway connector for the lighting system on cart to seven pin connector on tractor. If your tractor is not equipped with SAE Standard 7 terminal connector, obtain through your local tractor supply dealer. Check clearance lights, signal lights, and auxiliary work light are working properly.
- 11. Secure hoses and harnesses on tracotr side, to provide clearance to the PTO Shaft and hitch.
- 12. Connect optional electric roll tarp and camera harnesses. Check for proper operation.



Handheld Remote Control





Joystick side view

- Push trigger to open flow gate.
- Pull trigger to close flow gate.
- Press horizontal AUGER ON/OFF button to start the horizontal auger. Press button again to stop horizontal auger. Indicator light on button is lit when auger is on.

Operation

- Pivot IN/OUT moves vertical auger +/- 10° from cart.
- Spout IN/OUT adjusts "tippy spout" position.
- Push JOYSTICK LEFT or RIGHT to position vertical auger out from cart.
- Push JOYSTICK UP or DOWN to position vertical auger spout.



CART OPERATION

r	
WARNING	Contact with rotating driveline will cause death or serious injury. Keep away at all times when operating. Never operate without all guards and equipment shields properly installed.
WARNING	Towing loaded grain carts on public roads and bridges can result in death, serious injury, and damage to property and equipment. Never tow a loaded grain cart on public roads and bridges.
WARNING	Limited window visibility can conceal people, animals, or objects and result in death, injury, and damage to property or equipment. Check completely around cart before moving!
	Wide loads or loads with a high center of gravity may cause instability or rollover when operating on hillsides or in rough terrain.
	Do not transport cart with vertical auger extended. This can cause loss of control and could result in death, serious injury, or damage to property or equipment.
WARNING	Falling from equipment can cause death or serious injury. Use three points of contact when working on equipment. Never ride on equipment!







Unload Grain Cart



NOTE: Vertical auger tilt must be in fully retracted position to fold/unfold.

- 1. Open roll tarp completely.
- 2. Unfold vertical auger.
- 3. Engage PTO at low tractor RPM.
- 4. Engage horizontal auger.
- 5. Start to open flow gate and increase tractor RPM.
- 6. Set grain flow and tractor RPM to desired level.
- 7. Adjust auger tilt and/or tip spout.
- 8. Slow tractor RPM as cart reaches empty
- 9. Close flow gate
- 10. Disengage horizontal auger.
- 11. Allow vertical auger to clean out and disengage PTO.
- 12. Ensure auger tilt is in full vertical position.
- 13. Fold auger to storage position.



PTO TORQUE LIMITING/OVERRUNNING CLUTCH PROTECTION



The torque limiting clutch disengages if auger becomes obstructed to prevent driveline and gearbox damage. The torque limiting clutch resets automatically when PTO RPM is reduced.

The overrunning clutch allows auger system to freewheel and protects tractor and cart from shock damage withPTO brake-equipped tractors.

BELT ENGAGEMENT INDICATOR

An indicator pointer on front side of belt housing shows if horizontal auger is engaged (ON) or disengaged (OFF).

indicator should be OFF when PTO is engaged to reduce start up torque requirements.

As belt tension is disengaged (OFF) you will hear linkage snap over center and release belt tension.



Belt engagement indicator



Flow gate position indicator

HYDRAULIC FLOW GATE

Hydraulic flow gate controls volume of grain to horizontal auger. An indicator on front panel shows position of flow gate.

- 1. Engage PTO for the vertical auger at low RPM.
- 2. Engage belt drive clutch to start the horizontal auger.
- 3. Open gate half way.
- 4. Adjust flow gate to desired unloading rate.

NOTE: Recommended initial flow gate position for rice is half open.



AUGER INSPECTION COVER



Vertical Auger Cleanout door



Horizontal Auger Cleanout door



Grain Carts are equipped with two inspection covers one at the bottom of the vertical auger and one located on the grain transfer that are used for clean out purposes.

The inspection covers should be removed any time total clean out of the wagon is required, such as when changing crops, to preserve grain identity, or in preparation for storage.

At the end of each season or after extended use, the inspection covers should be removed and the auger chamber cleaned of all debris and accumulated grain to prevent rust and mold.

Reinstall covers and tighten hardware evenly after clean out is complete.



GRAIN TANK CLEAN OUT SWEEP

DANGER	Never use clean out sweep while PTO and/or augers are running.
	Never remove dump door while PTO and/ or augers are running.
	Never work around PTO, gerabox, or belt drive system or allow anyone else to do so while PTO is running.
DANGER	Contacting rotating auger will cause death or serious injury. Never open or close dump door with auger operating. Remove power source before using cleanout sweep or working on equipment.
	Flowing grain could trap and suffocate
	resulting in death or serious injury. Ensure grain has been emptied from cart before opening dump doors or working on equipment.





Rear Inspection Cover

To access the grain tank clean out sweep, remove the slide pan nut and heavy washer at the bottom of the rear inspection cover. Remove the wing bolts that secures clean out sweep and remove the covers and dump door(s) on the underside of the grain tank. Set hardware aside.

Remove the auger inspection cover at the front of the wagon by removing nuts.

Remove the wing nuts holding the rod storage cover plate and remove extension rods. Connect extension rods together and attach to clean out sweep. Attach hex socket set screw, slide pan washer, and slide pan nut to the rod end containing the push stop, creating a handle.

Remove cleanout door handle from storage location. Attach handle to hex shaft, crank handle counter-clockwise to open cleanout doors.

Attach extension rods and pull the clean out sweep as far back as possible then push it as far forward as possible. Repeat this procedure several times. Inspect the inside of the wagon to ensure clean out is complete.

Reinstall auger inspection covers and dump door(s) at front of wagon and dump door on underside of grain tank at rear of wagon. Store clean out sweep extension rods and reinstall and tighten all hardware.

Dump Door Adjustment

Turnbuckles are located on the bottom of each dump door.





VERTICAL AUGER WORK LIGHT

Work light is mounted in a fixed location on the vertical auger and cannot be moved. Limited adjustments can be made by swiveling light on its base.





MANUAL AND ELECTRIC ROLL TARP

NOTE: Mount the circuit breaker as close to the power source as possible. Direct connection to the battery or a primary battery-direct power buss is advised. Run 6ga minimum wire size to the tarp system connector plug.

Electric Roll Tarp can be operated with remote or Manual switches.

Close Tarp: Push switch to **CLOSE** and hold. Observe trap and release switch when tub is fully closed.

Open Tarp: Push switch to **OPEN** and hold. Observe tarp and release switch when tub is fully opened.

Power-up/down:

The transmitter will power up when the lid is opened. The transmitter will power down when the lid is closed or when the lid is left open three minutes after the last button is pushed.

Standard operation:

After power-up, the first channel will be immediately active and the LED indicator for this channel will be flashing. The *Open/On* and *Close/Off* buttons are operational for the indicated active channel. While pressed, the LED indicator will flash faster, indicating channel operation.

The *Select* button will cycle between enabled channels. If only one channel is enabled, there will be no apparent change when the Select button is pressed.

Channel programming mode:

The Shur-Co[®] SMART1+ has five channels. Pressing the Select button toggles through these channels. Unused channels can be disabled if desired, using the following process, but your transmitter is fully operational as shipped. This process may be skipped. Unused transmitter channels will not perform any functions.

Hold the Select button down for 10 seconds and the transmitter will enter *Channel Programming Mode*. Each time *Channel Programming* Mode is entered, the status of all five channels must be reset.

While In Channel Programming Mode, the programmable channel will be indicated by a solid lit LED.

NOTE: The transmitter will NOT activate any motor or lighting system while the transmitter is in *Channel Programming Mode*.

Press the *Open/On* button to enable the current channel (designated by the indicator light). Press the *Close/Off* button to disable the current channel. The indicator light will automatically jump to the next channel.

After programming all five channels, the transmitter will display the programmed channel status for all channels for three seconds. All enabled channel LEDs will be lit solid and all disabled channel LEDs will not be lit. Buttons will not function during this three second period.

The transmitter will automatically exit *Channel Programming Mode* after three seconds and return to *Operational Mode*.

NOTE: If there is not at least one enabled channel after programming, the transmitter will not save the changes and will revert back to the previously saved channel settings.

TIP: To cancel your changes and exit Channel Programming Mode, close the transmitter cover.



Channel programming example:

The transmitter in this example is labeled with the following five channels:

- Tarp System
- Front Hopper
- Back Hopper
- Lights
- Auxiliary

These channel labels are for a standard agricultural transmitter. Your transmitter label may differ.

The task is to enable the Tarp System, Front Hopper and Back Hopper channels.

1. Hold down the *Select* button for 10 seconds. The transmitter will enter *Learn Mode*. The *Tarp System* channel LED will be lit. All other channel LEDs are off.

2. Press the Open/On button to enable the Tarp System channel. The Front Hopper LED will now be lit.

- 3. Press the Open/On button to enable the Front Hopper. The Back Hopper LED will be lit.
- 4. Press the Open/On button to enable the Back Hopper. The Lights channel LED will be lit.
- 5. Press the Close/Off button to disable the lights. The Auxiliary LED will be lit.

6. Press the Close/Off button to disable the Auxiliary channel LED.

7. The transmitter will display all activated channels for three seconds. The transmitter will automatically exit *Channel Programming* and revert to *Operational Mode*. The *Tarp System* LED will be flashing, indicating that the channel is active and ready for operation.

SMART1+ to receiver programming:

Shur-Co[®] SMARTrailer[®] wireless systems are typically pre-programmed at the factory or by the dealer and should be ready to use as shipped. Re-programming is necessary after replacement transmitters or receivers are installed. Use the following method to program the RF receiver to accept and respond to signals from up to five transmitters. The receiver will not accept or respond to signals from transmitters that have not been programmed using this method.

1. Remove the receiver cover, pulling gently on the cover to prevent damage to wires that are connected to the rocker switch.

2. Check to be sure the electric tarp is connected to the power supply. The receiver must be connected to power to be programmed. If a battery disconnect switch is installed, make sure it is turned on.

3. The receiver can learn to recognize and respond to up to five transmitters. Gather all of the transmitters to be introduced to the receiver. Open the transmitter lid(s) in order to turn them on.

4. Set the transmitter(s) to the appropriate channel (Tarp System, etc.).

NOTE: Read the following steps in their entirety before proceeding. Steps 6 to 8 must be completed within 20 seconds.

5. Press and hold the blue programming button on the back of the RF module for 5 seconds. The RF module is located in the back of the cover.



Single SMART1+™ remote:

1. On remote, press Open/On button five times. Red light on receiver will flash after each button press. After receiving last signal, light will flash twice, then begin flickering, indicating it has been successfully programmed.

2. Verify remote and receiver are operating correctly, then refasten solenoid cover.

Multiple SMART1+™ remotes:

1. Press Open/On button on first remote. Red light will flash after receiving signal.

2. Repeat above step for each remote being used.

3. Receiver will accept up to five signals. Press Open/On button additional times on last remote being programmed to achieve total of five signals. Red light on receiver will flash twice after last (fifth) signal, then begin flickering, indicating it has been successfully programmed (see programming example).

4. Verify each remote and receiver are operating correctly, THEN REFASTEN SOLENOID COVER.

Receiver programming example:

In this example, the receiver controls the electric tarp motor. The task is to program the receiver to recognize three transmitters.

1. Remove the receiver cover and turn on the three transmitters.

2. Set all three transmitters to the tarp system channel.

3. Press and hold programming button on receiver for five seconds. Red light on receiver will fl ash to indicate it has entered Programming Mode. Release programming button. Light will now turn off.

4. Press Open/On button on first remote. Red light on receiver will flash to indicate it has received signal and memory slot #1 has been filled.

5. Press Open/On button on second remote. Red light on receiver will flash to indicate is has received signal and memory slot #2 has been filled.

6. Press Open/On button on third remote. Red light on receiver will flash to indicate it has received signal and memory slot #3 has been filled.

7. Press Open/On button on third remote again. Red light on receiver will flash to indicate it has received signal and memory slot #4 has been filled.

8. Press Open/On button on third remote again. Red light will flash twice to indicate it has received signal and memory slot #5 has been filled. It will then begin flickering, which indicates receiver has exited programming mode.

9. Verify front hopper Open and Close operations are functioning CORRECTLY ON ALL.

10. Refasten the receiver cover to motor assembly.



ROLL TARP REMOTE CONTROL TROUBLESHOOTING

PROBLEM	SOLUTION	
No lights on remote turn on when I open the lid.	Close lid for three seconds, then reopen lid.	
	Make sure there are no magnets close to the transmitter.	
	Open transmitter case and make sure battery is placed correctly in the remote.	
	Remove battery and bend contacts closer together. Put battery back in and try again.	
	The battery may be dead and must be replaced. Replacement quantity is 2 "AAA" batteries.	
	SMART1+ is damaged and must be replaced.	
I can operate the system with rocker switch but not the remote. The SMART1+ channel light is blinking, and when I	Make sure remote is set to the right channel. If you cannot set remote to the desired channel, it must be reprogrammed (see transmitter programming instructions).	
press the Open/On button, the light blinks	Make sure no other transmitters are being used near your system.	
faster.	Determine if the transmitter is the problem by testing it with a different receiver or by using a second remote. If receiver was the problem, reprogram receiver (see the receiver programming instructions). If this doesn't work, receiver should be replaced.	
	Make sure you are within a couple feet of the receiver and try again. If transmitter works at short range but not at greater distances, you have a range problem, so a new battery may be needed. If the remote battery is not the cause, call the Help Line.	
The SMART1+ channel light is blinking, but when I press the Open/On or Close/ Off button, the light goes out or just continues to blink at the same speed.	Remove battery and bend contacts closer together. Put battery back in and try again.	
	The battery may be dead and must be replaced. Replacement quantity is 2 "AAA" batteries.	
	SMART1+ is damaged and must be replaced.	



TRACK SYSTEM COMPONENTS - MODELS 1321/1421/1521



Frame

The main frame consists of a casting, and the front alignment yoke and rear tension link are cast members.

Axles

Front and rear axles are machined from the yoke castings, allowing for dimensional stability and few moving parts. They feature oil bath hubs mounted on tapered bearings and mechanical seals for extreme working conditions. Each hub has its own oil reservoir with access port for maintenance and checking oil levels. Refer to Lubrication and Maintenance section for oil fill and greasing information.

Idlers and Midrollers

The idlers have the function of guiding the rubber track by acting on the lateral surfaces of the guide lugs. Rotation of belts is recommended to extend life.



TRACK SYSTEM COMPONENTS - MODELS 1321/1421/1521 (CONTINUED)

Tensioning System



The tensioning system is located between the 2 rear idlers. The tension force is provided by a mechanical spring mechanism. Track tension is provided by the spring and does not need adjustment during operating and changing field conditions. Provisions are made to compress the spring allowing for removal of idlers and track assemblies during maintenance and servicing. Special tools are available from Kinze to compress the spring and detension the tracks.

Rubber Tracks

Rubber tracks are manufactured with high quality rubber and high strength steel cabling inside. The tread layout ensures good flotation, excellent life, and self-cleaning characteristics.

TRACK TRANSPORT SPEEDS - ALL TRACK MODELS

Model	Operating Condition	Transport Speed (Maximum)	Transport Duration (Maximum)
1721	Empty	15 mph (24 kph)	30 minutes
1321/1421/1521	Empty	25 mph (40 kph)	30 minutes

NOTE: Track carts should be limited to road use only when empty.

If additional distances are required, a 30 minute cool down period is recommended before transport is resumed. Absolute speed and duration levels may vary, depending on system type and ambient conditions. Recommended speed and duration information help avoid system heat buildup that could cause reduction in track life.



TRACK SYSTEM MINIMUM TURNING RADIUS LIMITATIONS - ALL TRACK MODELS

On either field or road, the minimum turning radius is 3 times the overall length of the tractor plus the implement.

Track systems operate best when running straight or in gentle turns. If a track system is pivot or spot-turned, the opportunity exists for soil and dirt to be ingested into the system. Even though the track system has a tension recoil system, if that tension recoil is exceeded, high loads in the frame and track can be generated which may cause track or system damage.



Minimum turning radius limits should be strictly observed to avoid damage to track system.

TRACK SYSTEM BREAK-IN PROCEDURES - ALL TRACK MODELS

Guide lug wear is reduced when correct break-in procedures are followed. During the break-in period, rolling components undergo a polishing-in process to achieve a smooth steel to rubber interface with the guide lug. Rubber uses dust and dirt as a dry lubricant during break-in and operation to minimize heat and reduce rubber stickiness. New tracks should be exposed to dry and dusty soil conditions as soon as possible. Operation without dust or soil in the system, especially during high speed roading, generates high levels of damaging heat. If roading must be done, a dry lubricant such as soil, talc, graphite, oil dry should be applied to the guide lugs periodically during roading until field operation resumes.





TRACK SYSTEM OPERATIONAL GUIDELINES - ALL TRACK MODELS

- Any application differing from the ones prescribed in this manual is to be considered improper and potentially dangerous.
- Correct track tension is required for best performance and track life.
- Track system can work in extreme conditions: for operator and machine safety, be sure to know your surroundings.
- Track system is free to pivot around the main axle following ground conformation.
- During transition over uneven ground terrain, check for interferences and move slowly to avoid over-oscillating the undercarriage.
- Overall width and height of machine/equipment with track system could differ from the original width and height with tires. Be sure to know actual machine height and width as well as width restrictions prior to operation.
- Cross large ground irregularities with suitable speed reduction and/or proper incidence angle. In particular, when high, sharp bumps are crossed move forward slowly to avoid shocks on the machine.
- The track system does not damage standard road-bed constructions. Operators must know and respect road traffic laws.

Rubber tracks have not been designed for extended use on the road. Kinze is not responsible for track and system damage resulting for extended road use. Long road periods and/or roading at higher than recommended maximum speeds may cause premature wear or failure of the track or wheels. To reduce damage during roading, decrease overall machine weight and decrease machine speed, refer to <u>"Track Transport Speeds - ALL Track Models" on page 2-18</u> for further information.

- Long runs on side slopes increase the wear on the side of guide lugs and idlers.
- Keep material out of the undercarriage. Inspect undercarriage daily and remove any material as necessary. In some conditions inspect more frequently.
- If a machine becomes stuck, clear away as much material from the undercarriage as possible prior to pulling the machine out.
- Avoid short turning radius turns and operation(s) especially when loaded. Spot turning creates debris ingestion and can also induce high torque loading in the system.
- Configure drawbar and hitch correctly during field operation(s).
- Use caution when operating track systems in loose, flowing material. Loose material can become trapped between track and idlers, resulting in track damage.
- Keep material out of the undercarriage. This may require scraping material out of tight places and in some conditions require frequent inspection and cleaning.


ELECTRONIC SCALE - GT 400

Electronic scale option includes four load cells, one hitch weigh beam, a tractor-mounted scale indicator console and cables, brackets, and mounting hardware.

To measure what is unloaded, press "TARE" before starting to unload. Weight being unloaded displays as a negative value. Record this information and press "NET/GROSS" to return to gross weight.

To measure what is loaded (For example when doing a field yield check.), press "ZERO" to zero cart weight before loading.

NOTE: Scale is most accurate when cart is sitting still on level ground when weighing.



GT 400 Indicator



Entering Field ID

A user-entered, 6 character identification number is used for referencing fields, trucks, owners or other information.



FIELD displays and a flashing cursor or character displays in the first position.

Step 2 Press

to scroll available characters.

Hold for 4 seconds to increase scroll rate.

Step 3 Press

to scroll back.

Press to move to next character.

Step 4 Press

to accept and save.

See GT 400 manual provided and Troubleshooting Section of this manual for additional information.

Scale Setup and Calibration Numbers
Flotation and Track
Setup Number: 127100
Calibration Number: 42546



Turn on Output to Display - GT 400				
Step 1	Push and hold			
	Until it scrolls, press select or net for Menu's 1,2,3,4,5, etc.			
Step 2	Press and hold			
	until Menu 2 appears			
Step 3	Press onvor			
Step 4	Press until 22 comes up.			
Step 5	Press on off until "COMIN" appears.			
Step 6	Press until "EZ2CMD" appears.			
Step 7	Press on repeatedly until "EXIT" appears			
Step 8	Press once more to return to weight mode.			



ELECTRONIC SCALE - GT 560

NOTE: Indicator must be on active screen before loading or unloading.

Suggested Operating Procedures - With AutoLog

NOTE: Movement of cart causes scale indicator reading to fluctuate.

Step 1 Press

Step 2 Press and hold zero balance the GT 560 indicator if the container is empty. Active screen is displayed.

NOTE: To operate GT 560 with AutoLog, the GT 560 must be connected to a PTO or switch sensor and AutoLog must be turned ON.

- Step 3 Press 🌇
- **Step 4** Press and to select field name.
- Step 5 Press not select required field name.
- Step 6 Press for to select required ID.
- NOTE: Make sure active screen displays.
- **Step 7** If AutoLog is enabled, start the PTO or open the discharge door. The GT 560 will display zero and enter the net mode.
- **Step 8** Unload grain. Upper Display shows amount unloaded. Gross value (total amount left on cart) displays on second line of Lower Display.
- Step 9 If AutoLog is enabled, stop the PTO or close the door. The data record will be stored in memory of indicator. The data record screen will display the last data record for 10 seconds, then return to active screen.
 Refer to GT 560 manual for additional information.

Scale Setup and Calibration Numbers Flotation and Track Setup Number: 127100 Calibration Number: 42546



GT 560 Indicator

Suggested Operating Procedures - Without AutoLog

NOTE: Movement of cart causes scale indicator reading to fluctuate.

Step 1 Press



NOTE: To operate GT 560 without AutoLog, the AutoLog feature must be turned OFF.

- Step 3 Press 🌇
- **Step 4** Press and to select field name.
- **Step 5** Press **ID** to select required field name.
- Step 6 Press to select required ID.

NOTE: Make sure active screen displays.

- **Step 7** Press (START) before unloading grain from container. The GT 560 will display zero and and enter the net mode.
- **Step 8** Unload grain. Upper Display shows amount unloaded. Gross value (total amount left on cart) displays on second line of Lower Display.
- **Step 9** When unloading is complete, the data record will be stored in memory of indicator. The data record screen will display the last data record for 10 seconds, then return to active screen.

Step 10 Press when finished unloading grain. Refer to GT 560 manual for additional information.







SCALE-TEC POINT

Electronic scale option includes four load cells, one hitch weigh beam, a tractor-mounted scale indicator console and cables, brackets, and mounting hardware.

To measure what is unloaded, press "START/PAUSE" before starting to unload. Weight being unloaded displays as a negative value. Record this information and press "STOP" to return to gross weight.

To measure what is loaded (For example when doing a field yield check.), press "ZERO" to zero cart weight before loading.

NOTE: Scale is most accurate when cart is sitting still on level ground when weighing.

NOTE: POINT Mobile app and internet connectivity to Android or iOS device is required for initial set up. However, internet service (cellular data/WiFi) is not needed to function in the field.

Scale-Tec POINT Mobile App

- 1. Download and install the Scale-Tec Mobile app.
- 2. Create an account. Android: See "Getting Started: Creating a POINT Account (Android)"

IOS: See "Getting Started: Creating a POINT Account (IOS)"

3. Register and Setup your device. Android: See "Getting Started: Registering and Setup of Your POINT Device (Android)".



IOS: See "Getting Started: Registering and Setup of Your POINT Device (IOS)".



Start / Pause

Operating Procedures

Step 1. Press On/Off button to turn on monitor.

Step 2. Zero Scale

Display: Press and hold Zero button three seconds. App: Press Zero.

NOTE: To operate POINT with PTO sensing/ISOBUS, it must be connected to a PTO or switch sensor.

Step 3. Load cart.

Step 4. Begin unloading.

If operating without PTO sensor or ISOBUS cable, press "START/PAUSE" before unloading and "STOP" after unloading is complete.

Step 5. Unload cart.

Negative reading on scale indicator is pounds unloaded.

Step 6. Unloading complete. Press Stop button when unloading is complete. NOTE: Indicator displays remaining weight left on scale.

Repeat Steps 4-6 each time cart is unloaded.

Refer to Scale-Tec's knowledge base at <u>www.scale-tec.com</u> for user guides, FAQs, and online support.

See troubleshooting section of this manual for additional information: "POINT ISOBUS Troubleshooting" on page 2-29 "Enable ISOBUS PTO and GPS Detection For Use With REAP" on page 2-31



AUXILIARY SCALE DISPLAY

Auxiliary Scale Display, requires electronic scale package. Display size 20.25" x 5.83" x 1.00" sealed in a polyurethane epoxy, 6 digits 4" tall sunlight readable LEDs, 50' cable, 6 magnets included to place in preferred location for viewing by combine operator.

NOTE: Do not place scale display over decals, magnets may ruin decals.



To configure auxiliary scale display, see <u>"Electronic Scale - GT 400" on page 2-21</u> or <u>"Electronic Scale - GT 560" on page 2-23</u>

ELECTRONIC SCALE - GT 560 AUTOLOG



The GT 560 indicator has many features but it also boasts simple handsoff operation using a RPM sensor on the PTO shaft to trigger the start of the unloading process and the end of the unloading process. AutoLog prevents operator mistakes that could cause you to lose data on loads because the operator "Forgot" to push the "Start/Stop" key. You can still use "Start/Stop" key before unloading and again after unloading in case the sensor is damaged or not functioning for any reason. Weight, date, time, and additional information is stored automatically after each load is completed.

See GT 560 AutoLog Operators Manual provided and Troubleshooting Section of this manual for additional information.





ELECTRONIC SCALE TROUBLESHOOTING





1.	Check to make certain that the cables	When connecting POINT to ISOBUS the power port on the far left should be empty.							
	are connected correctly.	The ISOBUS harness that provides power and connects POINT to the tractor must be plugged into the DT8 port on the far right of POINT.							
		of tractors is often dirty and the connector may not have a good retaining mechanism.							
2.	Make sure the POINT firmware is on an a 2.1.4 or later for PowerUp.	irmware is on an appropriate version. Newest is typically best but must be 1.8.15 or later for VT and Up.							
3.	Make sure the correct settings are applied. This can be done using "Choose Mode" or by changing	ISOBUS - ON: this mode enables the POINT to display on the VT and send basic weight information over ISO. This mode changes the CAN Mode parameter to ISOBUS.							
	individual settings.	PowerUp: this mode enables all of the features in ISOBUS - ON in addition to allowing POINT to receive the PTO status messages from the tractor. This mode changes the CAN Mode parameter to ISOBUS and the ISOBUS Message Filter Bitmask parameter to PTO Filter Active.							
4.	Power cycle the tractor.	When the tractor key is turned off, the POINT and the tractor display should also shutdown.							
		When the tractor is restarted, allow for the tractor display to fully restart. It can take several minutes after the tractor is running.							
		Does the POINT show up on the VT after the tractor has been power cycled? Yes - Step 5 No - Step 7							
5.	POINT appears on the VT. Is this	No - The system is working correctly							
	customer utilizing PowerUP?	Yes - Step 6							
6.	Turn on the PTO and watch the POINT indicator to see if it changes from	If POINT reacts to the PTO being turned on and off, the system is working correctly.							
	GRUSS (0 LUADING/UNLUADING.	 If POINT does not react to the PTO, the tractor is not sending the correct PTO status messages. This can be true for several reasons: a. The tractor software is out of date. This is common on 2008-2012 models. Have a dealer update the tractor. b. The tractor did not come from the factory with integrated ISOBUS. This is common on tractors made prior to 2010. c. The tractor did not come from the factory with an integrated PTO. High horsepower tracked equipment marketed for tillage are often sold without a PTO or the PTO may be a dealer add-on. d. The tractor does not conform to ISOBUS messaging standards. CAT Challenger C,D, and E series tractors do not transmit PTO status. 							

DOINT ISOBUS TROUBLESHOOTING



7. Test for CAN HI and CAN LO at the DT8 end of the ISO Harness 8. If any part of step 7 testing fails or if the problem is intermittent in nature, replace the Scale-Tec ISO Harness. 9. If all tests in step 7 pass, perform a factory reset on the POINT, reapply the profile/cal number, and repeat steps 3-5. POINT ISOBUS Troubleshooting. Retrieved March 27, 2025 from https://support.scale-tec.com/portal/en/kb/articles/point-isobus-troubleshooting

POINT ISOBUS TROUBLESHOOTING



ENABLE ISOBUS PTO AND GPS DETECTION FOR USE WITH REAP

POINT now allows both the detection of PTO status and GPS coordinates over ISOBUS. If a StarFire receiver is connected, POINT will use its position data to add Lat./Lon. coordinates to each load ticket that is recorded. To enable these features, follow the steps below. The POINT must be connected to ISOBUS using a HarvestMate cable (7609060).

1. Update Firmware (must be 2.2.6 or newer)

FIRMWARE UPDATE

- Make sure the POINT app on your mobile device is updated to the most current version. Most users already have automatic updates enabled on their mobile devices. This is the easiest way to keep all of your mobile apps updated to their current versions. If you have automatic updates enabled on your mobile device, continue to step 2. If you do not have automatic updates enabled, or you do not know, please see this help article to ensure you have automatic updates enabled on your iOS app.
- 2. Turn on your POINT scale display.
- 3. Watch the video available online for visual instructions, or continue reading the step-by-step instructions.
- 4. Open the POINT app on your iPhone or iPad.
- 5. In the app, select your POINT device.
- 6. Tap the device name above the weight (ex: Device:POINT-1-XX:YY).
- 7. Select "Firmware" from the menu.
- 8. On the next screen, press "Update Firmware."
- 9. On the next screen, press "Start" make sure you have a good internet connection.
- 10. During the process, your POINT device may power off and on several times. There is no need to turn it back on during the update process.
- 11. When the screen says "Firmware is up to date," you have completed the process. In the app, if you want to return to the scale screen, press the arrow in the upper left corner of the screen.
- 2. Choose Mode and select "PowerUp"

FIRMWARE UPDATE

POINT has several modes that it can operate in.

- 1. To select a different mode, touch the "Choose Mode" button at the bottom of the live scale screen.
- 2. Once the Modes screen opens, select which mode you would like to use.
- 3. POINT will return to the Live Scale screen once the mode has been changed successfully.
- 3. Power-cycle the tractor. Turning the key off should power off both the tractor and the scale. When the tractor is restarted, the scale should connect to the ISOBUS and the features should be active.

POINT ISOBUS Troubleshooting. Retrieved March 27, 2025 from https://support.scale-tec.com/portal/en/kb/articles/enableisobus-pto-and-gps-detection-for-use-with-reap



PROBLEM	POSSIBLE CAUSE	SOLUTION	
Uneven tread wear	High amount of roading	Swap tracks side to side	
Splits/opening on the side or top of tread	High amount of roading or overheat of tread	Swap tracks side to side. Replace tracks if necessary.	
Chunking on guide lug sides	Track not aligned properly	Align track	
	Side slope operation	Contact dealer	
Breakaway of track guide lugs	Debris/material ingestion into track system	Contact dealer	
Correct tensioning not possible	Verify position of track detensioning bolt at rear idler assembly.	Bolt fully retracted with no preload on spri applied	
High temperature of idler or roller axle	Bearing failure	Replace damaged bearing.	
hub.	Lack of lubricant	Check oil level in reservoir.	
Mud/dirt buildup on idlers/midrollers	Operation in muddy, wet or sticky soil types	Clean mud/dirt regularly to prevent track damage.	

TRACK SYSTEM TROUBLESHOOTING



Proper lubrication of all moving parts will help ensure efficient operation of your Kinze Grain Cart and prolong the life of friction producing parts.

SPLINES

Clean and grease all splines before assembly to prolong life, and to prevent damage and ease disassembly when removing.



To extend life of shaft splines, apply a coating of high-speed industrial coupling grease, such as Chevron[®] Coupling Grease, that meets AGMA CG-1 and CG-2 Standards.

WHEEL BEARINGS

Wheel bearings should be checked and lubricated annually.

Raise wheel off the ground and remove the dust cap. Check for endplay in bearings by moving tire in and out. Rotate tire to check for roughness in bearings. If bearings sound rough, the hub should be removed and bearings inspected and replaced if necessary. See "Wheel Bearing Replacement" in Maintenance section of this manual.

If bearing replacement is not necessary, while wheel is raised and dust cap removed, pump grease into hub until grease comes out through bearing rollers. Replace dust cap.

TRACK ENDWHEEL AND MIDWHEEL **BEARINGS - 1721 MODELS ONLY**

Check bearings annually or after every 1000 hours of use, whichever comes first.

If bearings sound rough, hub should be removed and bearings inspected and replaced if necessary. If bearing replacement is not necessary, pump grease into spindle until grease comes out around seal protector on axles and midwheels.

See Maintenance section of this manual if endwheel or midwheel bearing replacement is necessary.



10 Bolt Hub Shown



1721 Track Model

HORIZONTAL AUGER BEARINGS

Check and lubricate bearing hubs annually.

Remove hub and inspect bearings If bearings sound rough. If bearing replacement is not necessary, pump grease into hub until grease comes out through seals.



See Maintenance section of this manual if bearing replacement is necessary.



DRIVE BELTS AND PULLEYS





4-Band V-Belts (2) Shown

See "V-Belt Tension Adjustment and Alignment" in Maintenance section for additional information.

GEARBOX OIL LEVEL

Gearbox Oil Capacity 1% Gallons SAE 90 weight oil.



Remove plug from fill/check plug hole on the gearbox. Oil level should be even with fill/check plug hole. Inspect oil at end of each annual season of use for moisture and contaminates, if found, change oil before storage.

PTO SHAFT COUPLING

Clean and grease PTO shaft coupling each time PTO is installed.

Apply a coating of high-speed industrial coupling grease, such as Chevron[®] Coupling Grease meeting AGMA CG-1 and CG-2 Standards to extend life of shaft splines.





GREASE FITTINGS

Those parts equipped with grease fittings should be lubricated at the frequency indicated with an SAE multipurpose grease. Be sure to clean the fitting thoroughly before using grease gun. The frequency of lubrication recommended on the following pages is based on normal operating conditions. Severe or unusual conditions may require more frequent attention.



Extreme operating conditions such as dirt, termperature or speed may require more frequent lubrication.

NOTE: Disconnect PTO from tractor. Retract PTO assembly and rotate shield to expose grease fitting on PTO slide.



Swivel Hitch (Qty. 1) 2022 - 2023 Production



Swivel Hitch (Qty. 1) 2024 Production and On



Row Crop Carts (10 Bolt Hub) Wheel Bearings (Qty. 1 Per Wheel Hub)



Flotation Carts (20 Bolt Hub) Wheel Bearings (Qty. 1 Per Wheel Hub)







NOTE: Numbers on illustrations below corresponds to photos on following pages showing lubrication frequencies.













NOTE: For 1321/1421/1521 Track Models, proceed to page 3-10 for Lubrication Information.



1.Intermediate Drive Line - 1 Zerk



3. Cam Rollers - 1 Zerk (2022 Production)



5. Grease Bank (Auger Drive Bearings) -1 Zerk Each



2. Vertical Auger Upper Bearing - 1 Zerk (2022 Production)



4. Vertical Auger Center Bearing - 1 Zerk (2022 Production)



6. Grease Bank (Auger Bearings) - 1 Zerk Each (2023 Production and On)









8.Fold Linkage And Hinge - 6 Zerks (2022 Production)



9. Model 1721 Track Only - Axle Pin - 1 Zerk Per Side Spindle Bolt - 12 Zerks Per Assembly, 6 Zerks Per Side



* Pump grease into spindles until grease comes out around seal protector on axles and midwheels.



TRACK SYSTEM MAINTENANCE

Every 50 Hours or Weekly

GREASE UPPER CARRIER HUBS, UNDERCARRIAGE AND TRACK SYSTEM PIVOT POINTS

Visually check oil in mid rollers through clear covers.



Every 100 Hours or Monthly

CHECK TRACK TENSION

System is self-tensioned via spring. Visually check track tension.

CHECK WHEEL BOLT TORQUE

NOTE: Always torque after wheel removal regardless of hours.



Wheel Bolt Torque Chart							
Size	Torque (N-m)	Torque (ft-lb)					
M20	620 +/- 124	457 +⁄- 91					



Every 500 Hours or Yearly

REPACK CARRIER ROLLER WHEEL BEARINGS



NOTE: Torque lock nut while rotating or oscillating hub. If any lock nut slot and lock washer tang are aligned, bend the aligned tang into the slot to lock in place. If no slot or tang aligns, tighten the locknut until the most nearly aligned slot and tang line up. Bend the aligned tang into the slot to lock in place.

Every 2000 Hours or Every 5 Years

DRAIN AND REPLACE IDLER AND MIDROLLER RESERVOIRS

Use 10W30 Universal Transmission/Hydraulic Oil

	Torque		Oil Qty.	
	N-m	in-lb	ML	OZ
Mid Roller Clear Cover	4.5 ± 1	40 ± 9	200 ± 15	9.8 ± 0.5
Mid Roller Plastic Fill Plug	3 ± 1	27 ± 9	290 ± 15	
Idler Metal Cover	r Metal Cover 15 ± 3 132 ± 27		17 + 1	
Idler Metal Fill Plug	34 ± 7	300 ± 62	500 ± 25	1/ ± 1



Off Season Storage

For optimum life, tracks should be stored indoors, in dry environment with a temperature between 40° - 77° (5° - 25° C). The tracks should not be exposed to direct sunlight or heat. No petrochemicals and related vapors, no electrical devices producing ozone should be placed in the same area.

Should it be necessary to disassemble the tracks from the undercarriage, lay them on the ground on one edge avoiding bending radius less than 30" (750 mm). Do not lay the rubber components on dirty surfaces contaminated by oil, grease or other chemical products

Do not paint rubber components.

Rev. 4/23



CHECK TRACK ALIGNMENT - 1321/1421/1521 ONLY

1. Prior to checking track alignment the implement should be empty.



- 2. Measure the inside distance left to right. Undercarriage toe must be parallel to within 1/4" (6mm). A suitable location for measurement is noted by arrows, shown on the diagram above, between the idler hub covers.
- 3. Pull the implement on a flat surface for a suitable time frame, allowing the belts to relax and move freely on the undercarriage rollers.
- 4. Drive in a straight line for roughly 200 feet and coast the tractor to a stop. Place the tractor in PARK and apply the emergency brake. Do not apply braking action during this process as sudden stops can affect track position during the alignment process.
- 5. Using a ¼" x 4" x 8" shim slide between the front midroller and guide lugs. Bridge guide lugs with the shim maintaining pressure on 2 lugs minimum.
- 6. If the shim fits freely between the lugs and midroller on both sides of the undercarriage the alignment is correct. It the shim binds and does not fit between the midrollers/guide lugs track adjustment is necessary.





TRACK ALIGNMENT PROCEDURE - 1321/1421/1521 ONLY

- 1. Remove the retainer lock plate cap screw and lock plate from the inboard and outboard sides of the track needing adjustment.
- 2. Loosen track alignment cap screw counterclockwise 1 1¹/₂ turns on the side of the undercarriage you want the track to move towards.
- 3. Tighten the track alignment cap screw on the opposite side to specification. (Cap screw torque is (221 ft-lb) 300 N-m. Tighten cap screw loosened in step 2 to the same specification.

NOTE: A single full turn is the standard increment during adjustment. Lessen this amount as final adjustment is approached.

4. Recheck track alignment and adjust until suitable clearance is obtained on both sides of the guide lugs.

NOTE: Lock plates are reversible for double the index increments. If needed, increase torque on the special cap screw slightly allowing advancement to a suitable lock plate position.

5. When alignment is complete, reinstall the lock plates and tighten cap screws to their required torque specification of (95 ft-lb) 130 N-m).



TRACK SYSTEM INSPECTION - ALL TRACK MODELS

Track System

Inspect track system for material build-up on frames and wheels. Clean material from undercarriage.

Idlers and Midrollers

Check the general condition of the idlers and midrollers, making sure material buildup is not occurring. If any material buildup is found, it must be removed or track damage may result.

Rubber Track Guide Lugs

Guide lugs keep the track on the track system. Proper alignment of the track is essential to improving overall life and decreasing operating costs. If track is misaligned or operating on side slope, guide lug wear or damage may occur. Also guide lug damage may occur if proper break-in procedures are not followed or system is operated outside the maximum speed recommendations listed in this manual. Monitoring guide lugs condition will alert the operator to an issue and generally if corrected early prior to loss of performance or durability.

Track Carcass

Inspect track surface to remove imbedded stones or debris. This contamination can work its way into the track and damage the steel cable.

Steel wire may come out from the track carcass without affecting the performance of the track. Remove loose wires by cutting them at the rubber surface.

Track Tread

Muddy soils usually cause limited wear, while roading long distances can bring about accelerated tread wear. Due to the crown of the road, and deflection in the system, the tread closest to the machine will tend to wear faster than the tread on the outer portion of the track. Adhere to speed and weight limitations. Refer to <u>"Track Transport Speeds - ALL Track Models" on page 2-18</u>.

Adjusting Track Tension - 1321/1421/1521 Only

Tension is pre-set at the factory and requires no adjustment during operation. Provision is made to detension the track system allowing for removal of the rubber track.



This page intentionally blank.

TRACK REMOVAL - 1321/1421/1521 ONLY



IMPORTANT: A detensioning kit (PN A24944) is required for track removal and available from Kinze. Contact your Kinze dealer.

NOTE: A Porta Power is also required for track removal. Kinze recommends Blackhawk 10 Ton Porta Power Model B65115.

1. Remove plugs on rear track frame.





2. Attach a cylinder end cap to each end of the Porta Power.





TRACK REMOVAL - 1321/1421/1521 ONLY (CONTINUED)

3. Install one end of Porta Power on existing hook located between rear idlers.

4. Place detensioning mount where plugs were removed in step 1. Install other end of Porta Power on mount and secure with two M16 bolts.

NOTE: Ensure Porta Power hose is positioned as shown to avoid interference when removing idler wheel.

5. Pump the Porta Power until the tensioning spring is fully compressed.









TRACK REMOVAL - 1321/1421/1521 ONLY (CONTINUED)

6. Remove the rear M20 idler wheel bolts and torque plate castings. Remove idler wheel.



7. Install cylinder lock plate on Porta Power cylinder. Install locking pin in cylinder lock plate.





Idler wheels weigh 200 lbs (90 kg) and will roll easily on a firm surface. Place a block under removed wheels to prevent rolling and potential injury.

8. Utilizing existing fork lift pockets or properly rated jack and safety stands, raise the undercarriage until there is sufficient clearance between the midwheels and track guide lugs.







TRACK REMOVAL (CONTINUED)

9. Using a suitable lifting device, lift the track belt slightly to provide clearance between the carrier and track guide lugs.

NOTE: If using a forklift or other steel lifting device, ensure the tines or lifting surface does not have sharp edges or track damage may occur.

10. Lift the track up and away from the undercarriage, placing in a suitable location. Place track on its side.

TRACK INSTALLATION - 1321/1421/1521 ONLY

- 1. Raise the undercarriage to allow for the lower surface of the belt to slide underneath.
- 2. Lift the track and install on the top carrier rollers. Push the bottom of the track under the midrollers aligning with the front and rear idlers.
- 3. Install the idler wheels removed previously, ensuring the guide lugs are positioned properly between the midrollers and idlers. Torque M20 bolts on idler wheels to 457 ft-lb (620 N-m).
- 4. Lower the undercarriage assembly to the ground.
- 5. Remove lock from Porta Power cylinder.
- 6. Release pressure from Porta Power and remove.



MID-ROLLER WHEEL SEAL AND BEARING REMOVAL AND INSTALLATION

1. Remove locking washer and thrust washer.





2. Remove hub to dislodge outer bearing cone and remove bearing from axle, then remove inner bearing cone.





3. Remove inner half of mid-roller face seal and load ring from collar ring.





Outer Face Seal

4. Remove outer face seal and load ring from hub.

NOTE: If replacing face seals only proceed to Step 2 in <u>"Mid-Roller Wheel Seal and Bearing Installation" on</u> <u>page 3-20</u>. If there was a bearing failure proceed to next step.

- If replacing bearings use a bearing driver from the opposite side to remove inner and outer beaing cups. Clean and inspect all parts for wear or damage.
- 6. If collar ring is damaged or leaking go to the Roller Axle Removal and Installation section for collar ring removal.





MID-ROLLER WHEEL SEAL AND BEARING INSTALLATION

1. Use a bearing driver to install both bearing cups in hub until they are seated firmly against inner shoulder of hub.



2. Use denatured alcohol to clean inner bearing cup and seal contact area. Wipe seal contact area with a clean lint free cloth.

NOTE: Be sure no alcohol is puddled in seal contact area.



3. Install load rings on face seals.

NOTE: Be sure load rings are correctly installed on face seals as shown below.





METAL FACE SEAL PREPARATION AND INSTALLATION

Metal face seals are made of a hard and brittle metal alloy with a highly polished contact surface. Never place seal rings face down on a hard or rough surface.

Before seal installation the undercarriage must be completely cleaned and dried. The hubs, bearings, and axles must be thoroughly cleaned an dried. Flood wash bearing cups and seal mounting areas with denatured alcohol or a fast evaporating electrical contact cleaner (use a pump type spray bottle to apply denatured alcohol). Wipe parts with a clean LINT FREE cloth. All parts MUST be free of dirt, debris, and grease. Replace any damaged parts.

Metal Face Seal Installation

Apply even pressure to outer edge of tool to install O-Ring and seal evenly in hub or axle.







1. Lubricate seal load ring with denatured alcohol use the service installation tool to install seal and load ring in hub.



2. Flood collar ring with denatured alcohol to remove any dust or lint from seal cup. Use installation tool to install face seal assembly on collar ring. Install inner bearing cone on axle.





3. Carefully install hub assembly on axle without dislodging inner bearing and face seal until face seals make contact. Hold hub assembly in Steps 4 and 5.

Install outer bearing cone.

NOTE: The hub MUST be held in place with slight pressure against face seals until lock nut is installed in Step 5.





4. Install thrust washer on axle, then install locking washer.





 Install locknut and tighen to 32 ft-lb (43 N-m). Rotate hub five revolutions and check nut for correct torque.



6. Align one of four lock nut slots in the lock nut with nearest tab on locking washer. Bend lock washer tab into slot.

NOTE: If slot and tab does not align rotate locknut clockwise to align with nearest tab.





7. Install a new hub cover O-Ring.



8. Install hub cover and six retaining bolts. Tighten bolts in a cross pattern evenly to 132 in-lb (11 ft-lb) (15 Nm).



9. Remove plug and fill hub with 7.3 fl oz (215 ml) of Northland Transdraulic Fluid or equivalent. Oil level must be at bottom of fill plug hole. Tighten plug to 25 ft-lb (34 Nm).




TOP ROLLER WHEEL AND SEAL REMOVAL

1. Remove track see "Track Removal - 1321/1421/1521 only" on page 3-14



2. Remove five mounting bolts, remove top roller wheel, and then remove hub cover.





3. Bend lock washer tab out of lock nut, remove lock nut and lock washer.







4. Remove thrust washer, remove outer bearing, and remove hub.







TRACK TENSION - MODEL 1721 ONLY



There should be approximately 2" sag in track at midpoint between front and rear end wheels.

1. Lay a straight edge across complete length of track. Measure distance between track and straight edge at midpoint.

NOTE: It is normal for centering lugs to lightly touch the bottom of channel at top center of track chassis.

- 2. Loosen four ³/₄" attachment cap screws on inside sidebar and four ³/₄" attachment cap screws on outside sidebar on one end (front or rear) of track assembly.
- 3. Turn 1" adjusting bolt on end of each sidebar in or out equal amounts according to adjustment needed.
- 4. Retighten four ³/₄" cap screws on each sidebar.
- 5. Lay a straight edge across complete length of track. Measure distance between track and straight edge at midpoint and repeat steps as needed. It may be necessary to repeat procedure on opposite end of track assembly.
- 6. Torque hardware to 220 ft-lb (298 N-m).



TRACK ALIGNMENT - MODEL 1721 ONLY



Track centering lugs should run centered between end wheel segments as lugs enter end wheels when tracks are rotated. Misalignment may cause rubbing between track guide lugs and end wheel segments.

NOTE: Extending sidebar (turning 1" adjusting bolt clockwise) closest to end wheel showing evidence of misalignment or retracting sidebar (turning the 1" adjusting bolt counterclockwise) on end wheel on opposite side will move centering lugs away from end wheel.

- 1. Loosen four ³/₄" attachment cap screws on each sidebar and extend or retract sidebar(s) until proper alignment is obtained.
- 2. Retighten four ³/₄" cap screws on each sidebar.
- 3. Torque hardware to 220 ft-lb (298 N-m). Tighten inside and outside sidebars equally.



MOUNTING BOLTS AND HARDWARE

WARNING	Parts separation can result in death, serious injury, and damage to property and equipment. Check all hardware is tight before operating the grain cart the first time. Check all hardware again after first 50 hours of operation and beginning of each season. Check wheel nuts daily during first use and weekly afterward.
NOTICE	Over-tightening hardware can reduce its shock load capacity and cause equipment failure.

Hardware used on Kinze grain carts are Grade 5 (high strength) unless otherwise noted. Grade 5 cap screws are marked with three radial lines on the head. Hardware must be replaced with equal size, strength, and thread type.

	Grade 2 (No marks)			Grad	Grade 5 (3 marks)			Grade 8 (6 marks)				
Diameter	Coa	rse	Fin	Fine Coarse Fine		Coarse		Fine				
	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m
1⁄4"	50 in-lb	5	56 in-lb	6	76 in-lb	8	87 in-lb	9	9	12	10	13
⁵ ⁄16"	8	10	9	12	13	17	14	19	18	24	20	27
3⁄8"	15	20	17	23	23	31	26	35	33	44	37	50
7⁄16"	25	33	27	36	37	50	41	55	52	70	58	78
1⁄2"	35	47	40	54	57	77	64	86	80	108	90	122
⁹ ⁄16"	50	67	60	81	80	108	90	122	115	156	130	176
5⁄8"	70	95	80	108	110	149	125	169	160	217	180	244
3⁄4"	130	176	145	196	200	271	220	298	280	379	315	427
7⁄8"	125	169	140	189	320	433	350	474	450	610	500	678
1"	190	257	205	278	480	650	530	718	675	915	750	1016
11⁄8"	265	359	300	406	600	813	670	908	960	1301	1075	1457
11⁄4"	375	508	415	562	840	1138	930	1261	1360	1844	1500	2033
13⁄8"	490	664	560	759	1100	1491	1250	1694	1780	2413	2030	2752
11⁄2"	650	881	730	989	1450	1966	1650	2237	2307	3127	2670	3620

TORQUE VALUES CHART - PLATED HARDWARE

NOTE: Torque unplated hardware and bolts with lock nuts approximately ¹/₃ higher than above values. Torque bolts lubricated before installation to 70% of value shown in chart.

SPECIAL TORQUE VALUES						
Wheel nuts	350 ft-lb (474 N-m)					

Cylinder Rod Piston Retaining Nut Torque Chart

	V I							
	Non-Nylock Nut	Nylock Nut						
1/" 20	55-70 ft-lb	45-55 ft-lb						
/2 -20	(75-95 N-m)	(61-75 N-m)						
3/" 16	115-125 ft-lb	100-115 ft-lb						
/4 -10	(156-169 N-m)	(136-156 N-m)						
76" 11	150-180 ft-lb	130-150 ft-lb						
78 - 14	(203-244 N-m)	(176-203 N-m)						
1" 11	275-330 ft-lb	250-275 ft-lb						
1 - 14	(373-447 N-m)	(339-373 ft-lb)						
11/ 10	300-375 ft-lb	275-300 ft-lb						
178-12	(407-508 N-m)	(373-407 N-m)						
11/" 10	300-375 ft-lb	275-300 ft-lb						
1/4 -12	(407-508 N-m)	(373-407 N-m)						







VERTICAL AUGER COUNTER BALANCE VALVES



Counter balance valves prevent auger fold cylinder from extending or retracting without applied hydraulic pressure. If valve(s) fail to lock auger in position or fail to function properly, remove valve(s) from valve block and check for foreign material. Replace valve if defective.

WHEEL NUTS



Flotation Wheel Assembly



Soft Track Assembly

Wheels are attached to hubs with ten press fit studs through hub flanges and wheel nuts. Clean threads with a wire brush and oil lightly to retard corrosion when removing and installating wheels.

Torque wheel nuts to 350 ft. lbs. and retorque daily during first 3 days of use and weekly thereafter.

NOTE: Model 1721 Only: Torque hardware which attaches the segments to hubs to 220 ft. lbs.

NOTE: Models 1321/1421/1521 Only: Retorque all track system idler and midroller bolts daily during first 3 days of use and monthly thereafter. Torque bolts to 457 ft-lbs (620 N-m).



TIRE SERVICING



Explosive separation of rim and tire parts can cause death or serious injury. Overinflation, rim and tire servicing, improper use of rims and tires, or worn or improperly maintained tires could result in a tire explosion.

To prevent tire explosions:

- Maintain proper tire pressure. Inflating a tire above or below the recommended pressure can cause tire damage.
- Mount tires only by properly trained personnel using proper equipment.
- Replace tires with cuts or bubbles. Replace damaged rims. Replace missing lug bolts and nuts.
- Do not weld or heat wheel assembly. Heating increases tire pressure.

INFLATION SPECIFICATIONS



Over-inflation of tires can result in explosive separation of rim and tire and cause death or serious injury. Different size rims are designed for different tire pressures. Inflate to correct pressure for specific rim size.

Check tire pressure before each use.

1250/50R32 189 A8 (1321/1421/1521 Flotation Cart). 46 PSI (320 kPa)



Ø

Ø

V-BELT TENSION ADJUSTMENT AND ALIGNMENT

WARNING Never of cover is drive system of the system of th

Never operate cart when inspection cover is removed, or work around belt drive system or allow anyone else to do so while PTO is running or death or serious injury may result.



Do not use belt dressing V-belts. Keep all oil and grease off V-belts and multigroove pulleys. Low belt tension will reduce belt life.

//Indicator

0 0

Remove cotter pin

and washer

0



1. Remove cover and indicator.



Shown with covers removed.

2. Remove covers.





Lubrication and Maintenance



- 3. Inspect all linkages to make sure all components have been installed correctly and are moving freely.
- 4. Hydraulically engage the belt tensioner.
- 5. Check for free space (clearance) on the spring adjustment bolts between washers and mount.

There should be approximately 1/4"-3/8" (or the thickness of two-four washers) of clearance. Remove washers as required.

- 6. To remove washers, proceed as follows:
 - (a) Hydraulically disengage belt tension.
 - (b) Remove the 5⁄8" locking nuts and remove the spring adjustment bolts far enough to remove the required number of washers.
 - (c) Reinstall washers to head side of the bolt (d) Reinstall locking nut and tighten until nut "bottoms out" on the spring adjustment bolts.
- 7. After inspection and adjustments have been completed, reinstall side cover, indicator and cover.





V-belts are tensioned by a spring-loaded idler. Two springs are used to maintain even pressure across the V-belts. Set spring tension at 2³/₄" as shown above.



8. Collapse belt tension springs by tightening nylon lock nuts.





for clearance to remove belt from lower pulley.

9. Remove two bolts which secure idler assembly to

tower auger housing. Slide idler assembly to the side

10. Remove belts and install new belts.

NOTE: Replace V-belts as a matched pair.

- 11. Reinstall idler assembly.
- 12. Release belt engagement by loosening nylon lock nuts.
- 13. Adjust belt slide to within ¹/₈" of belts when tight.
- NOTE: Slide must not contact belts during operation.







14. Check and adjust belt tension.

NOTE: Do not use belt dressing on V-belts. Keep all oil and grease off V-belts and belt pulleys. Drive and driven sheaves (pulleys) do not need to be loosened to remove/replace V-belts. Low belt tension will reduce V-belt life.

15. Install all covers removed in previous steps **before operating cart**. Cycle hydraulic cylinder engaged in STEP 6, between extended and retracted positions to check proper engagement/disengagement of belt tension idler.

V-BELT ALIGNMENT

Pulleys must be aligned with the fixed idler position. Clearance of 2%" must be maintained between rear of belt pulleys and idler.

- 1. Tighten taper-lock bushing hardware.
- 2. Lay a straight edge across face of the drive and driven belt pulleys to ensure alignment between the grooves on the belts and pulleys and between the idler.

NOTE: Pulleys do not need to be loosened to remove/replace V-belts.

NOTE: V-belts should be replaced as a matched pair. See "V-Belt Replacement".





V-BELT REPLACEMENT

NOTE: Drive and driven sheaves (pulleys) do not need to be loosened to remove/replace belts.

NOTE: Cart must be attached to a tractor to use hydraulic system in later steps.

1. Disconnect PTO shaft from tractor.



2. Remove cover and indicator.





3. Remove additional covers.





Lubrication and Maintenance





- 4. Remove linkage bolt.
- 5. Push idler assembly away from belt.



6. Check and adjust spring dimension. See "V-Belt Tension Adjustment And Alignment"

NOTE: Replace V-belts as a matched pair.

7. Remove belts and install new belts.



- 8. Reinstall linkage.
- 9. Adjust belt slide to within $\frac{1}{8}$ " of belts when tight.
- 10. Install all remaining parts removed in previous steps in reverse order before operating cart.





DRIVELINE INSPECTION

Inspect driveline after first 20 loads, at beginning of each season, and after every 150 loads or annually thereafter.

Remove inspection cover and proceed as follows:

- □ Make a general inspection of driveline looking for loose hardware.
- Inspect belt alignment and tension. See "V-Belt Tension Adjustment And Alignment" in the Maintenance section of this manual.
- □ Inspect the three cap screws in each belt pulley bushing and tighten evenly to torque specifications.
- □ Inspect pulley drive keys making sure they are properly located and tight.
- □ Inspect all grease hoses for damage and proper routing.
- Lubricate all grease fittings. See Lubrication section of this manual.
- Check gearbox oil level.
- □ Inspect bearings and seals in gearbox.
- □ Inspect PTO attaching hardware and safety shields.
- □ Repair or replace worn or damaged parts.



UPPER VERTICAL AUGER REPLACEMENT



- 1. Position the vertical auger in a horizontal position as illustrated.
- 2. Remove ³/₄" hardware from center of bearing, ⁵/₈" spring plate hardware and ⁵/₈" spring mounting hardware.
- 3. Remove spring plate, flange bearing and sleeve.
- 4. Pull auger out of the bottom of the auger housing.
- 5. Remove 5/8" hardware securing bearing spindle and remove bearing spindle.
- 6. Install bearing spindle onto replacement auger. Install replacement auger inside auger housing. Locate auger with 1/2" (See Illustration) between bottom of hinge plate and end of auger assembly.
- 7. Reinstall sleeve, flange bearing and spring plate.



LOWER VERTICAL AUGER REPLACEMENT





- 1. Position vertical auger in the storage/transport folded position as shown.
- 2. Remove four ½" x 1½" hanger bearing bracket carriage bolts at upper end of lower vertical auger. Carefully work hanger bearing bracket loose from auger housing.

NOTE: Do not bend hanger bearing bracket when moving auger.

- 1. Position strap around auger as shown above. Be sure strap is tight against auger center tube. Pull auger and hanger bearing assembly out of auger housing.
- 2. Remove ¾" x 5" cap screw at top of lower vertical auger and remove hanger bearing bracket components from auger.
- 3. Remove four 5/8" x 2" cap screws that attach bullet spindle to top of lower vertical auger.
- 4. Install bullet spindle onto top of replacement auger aligning ³/₈" hole in auger with ³/₈" hole in bullet spindle.
- 5. Position hanger bearing bracket components onto top of replacement auger. Torque ³/₄" x 5" cap screw at top of lower auger to 200 ft. lbs.
- 6. Lower replacement auger into lower auger housing and onto lower drive lugs.
- 7. Position hanger bearing bracket with the split in the bracket in "up" position. Install four hanger bearing carriage bolts and nuts and tighten.





HORIZONTAL AUGER REPLACEMENT



Rear Inspection Cover

- 1. Remove 12 cap screws and lock nuts from rear inspection cover. Remove inspection cover and bearing hub assembly.
- 2. Pull horizontal auger through opening at rear of cart.
- 3. Install replacement horizontal auger with full pitch portion of auger to front and half pitch portion of auger to rear of cart.
- 4. Auger pilot plate on front of auger has one 3³/₈" pilot hole and four ³/₄" drive pin holes. Auger pilot plate at rear of cart has one 3³/₈" pilot hole and four ³/₄" drive pin holes.
- 5. Check auger engages drive pins at front and rear. Check rear spindle, hub, and bearings for roughness or wear. Replace worn or damaged parts and readjust bearing preload if necessary. Assemble hub with spindle into rear inspection cover.
- 6. Reinstall inspection cover, making sure drive pins on rear bearing hub engage mating auger holes properly. Torque hardware to specifications.

GEARBOX

The gearbox is equipped with a relief fitting which acts as a breather. The upper hole on the gearbox is used to check oil level or to add oil. Oil level should be even with the plug hole. See "Gearbox Oil Level" in Lubrication section of this manual for oil specifications and capacities.

A drain hole is located on the opposite side (bottom) of the gearbox.





TRACK ENDWHEEL/MIDWHEEL BEARING REPLACEMENT - MODEL 1721 ONLY

- 1. Position jack at axle and raise side of machine.
- 2. Mark position of inside and outside sidebars nearest end wheel being serviced.
- 3. Loosen four $\frac{3}{4}$ " cap screws and $\frac{1}{4}$ " spindle bolt on each sidebar.
- 4. Loosen 1" adjusting bolt on each sidebar.



Endwheel Procedure:

Remove sidebars on side next to endwheel being serviced.

Remove wheel cap screws and special washers that secure nuts for front half of endwheel segments and remove segments.

Remove endwheel.



Midwheel Procedure:

Remove sidebars on side next to midwheel being serviced.

Remove endwheel (See endwheel procedure above) nearest midwheel being serviced.

NIOTE: If there is a midwheel between endwheel and midwheel being serviced, it must also be removed.

Drop midwheel to clear track carriage and roll it to closest end of track for removal.



- 5. Remove double nuts and slide spindle from hub.
- 6. Remove bearings, seals and cups and discard. Clean and dry hub.
- 7. Press in new bearing cups with thickest edge facing in.
- 8. Pack bearings with heavy duty wheel bearing grease thoroughly forcing grease between roller cone and bearing cage. Fill space between bearing cups in hub with grease.
- 9. Place inner bearing in place and install seal.
- 10. Clean spindle and install in hub.
- 11.Install outer bearing, seal and stepped nut. Tighten stepped nut until there is some drag when the spindle is rotated. This assures that all bearing surfaces are in contact. Back off stepped nut 1/4 turn or until there is only slight drag when rotating hub. Install jam nut to lock against stepped nut.
- 12. <u>Endwheel Procedure:</u>

After endwheel has been reinstalled and segment hardware torqued to 220 ft. lbs., reinstall sidebars. Extend sidebars to previously marked positions and tighten all hardware. Torque ³/₄" cap screws to 220 ft. lbs. and 1¹/₄" spindle bolt to 1360 ft. lbs. Check track alignment and track tension. Adjust if necessary.

NOTE: Retorque endwheel segment, capscrew, and spindle bolt hardware as follows:

- a. After 4 hours use.
- b. After 16 hours use.
- c. Weekly during season.

Midwheel Procedure:

Raise midwheel assembly into position under the track carriage, install inner and outer spindle bolts and torque to 1360 ft. lbs. Install endwheel. Install the sidebars. Extend sidebars to the previously marked positions and tighten all hardware. Torque ³/₄" cap screws to 220 ft. lbs. and 1¹/₄" spindle bolt to 1360 ft. lbs. Check track alignment and track tension. Adjust if necessary.

NOTE: Retorque capscrews and spindle bolt hardware as follows:

- a. After 4 hours use.
- b. After 16 hours use.
- c. Weekly during season.

NOTE: Each midwheel and endwheel spindle bolt is equipped with a grease fitting (2 per assembly) for lubrication.



WHEEL BEARING REPLACEMENT



NOTE: See "Inside Tire Repair Or Removal" section of this manual for instruction on tire removal/access to inner wheel hubs on Row Crop carts.

- 1. Raise tire clear of ground and remove wheel.
- 2. Remove dust cap attachment hardware and remove cap from wheel hub.
- 3. Remove cotter pin, axle nut and 2" washer.
- 4. Slide hub from axle spindle, using a hub puller if necessary.
- 5. Remove bearings and cups from hub and discard. Thoroughly clean and dry wheel hub.
- 6. Press in new bearing cups with thickest edges facing in.
- 7. Pack bearing with heavy duty wheel bearing grease, thoroughly forcing grease between roller cone and bearing cage. Also fill the space between the bearing cups in the hub with grease.
- 8. Place inner bearing in hub and press in new grease seal with lip pointing towards bearing.
- 9. Clean axle spindle and install hub.
- 10. Install outer bearing, 2" washer and slotted hex nut. Tighten slotted hex nut while rotating the hub until there is some drag. This ensures that all bearing surfaces are in contact. Back off slotted nut to nearest locking slot and install cotter pin. Check for endplay in bearings.
- 11. Fill dust cap half full of wheel bearing grease and install on hub with attachment bolts.
- 12. Lubricate wheel nuts and install wheel. Remove jack. Torque wheel nuts to 350 ft-lb.

NOTE: Wheel hubs on Kinze grain carts contain high strength ductile iron material. Replace hub with proper part.



PREPARATION FOR STORAGE

Store machine in a dry sheltered area.

Remove all trash that may be wrapped on shafts and remove dirt that can draw moisture.

Remove auger inspection cover at front of cart and open cleanout doors at rear of cart. Clean out all accumulated grain and debris from auger chamber.

Wash machine inside and out.

Lubricate machine at all lubrication points.

If possible, remove weight from all tires, particularly if unit is stored outdoors.

Repaint any areas where paint has been removed. This is particularly important in the inside of grain tank. Rust in this area will shorten cart life and prevent grain from smoothly sliding to bottom of tank.

Inspect machine for parts in need of replacement and order during "off" season.

Coat exposed surface of all cylinder piston rods with grease or rust preventative spray.

HYDRAULIC HOSE LIFE



Proper storage of hydraulic hoses can significantly increase the life of the hoses, for a period of three to five years. After this period, service life of hoses may decrease, depending on variables such as variances in rubber materials and storage environment. Refer to the guidelines below for best practices when storing.

- Store in a clean, cool and dry area
- Avoid direct sunlight or moisture
- Do not store near high power electrical equipment
- Avoid contact with corrosive chemicals
- Avoid ultraviolet light
- · Avoid areas with obvious signs of insects or rodents

Unusually long periods of storage or poor storage environment may lead to performance issues or premature failure. Always inspect all hoses prior to use for extensive wear, cuts, or holes. If such flaws are identified, replace immediately to avoid potential failure, property damage or bodily injury.









HANDHELD CONTROL WIRING DIAGRAM







SW2

WIRE	FROM	то	GAUGE	WIRE COLOR	FUNCTION	CONTROLS	SWITCH POSITION		
W1	P1-1	SW1-1 SW2-C SW3-1 SW4-1 DS1-1	18	RED	+12V	COMMON POWER			
W2	P1-2	DS1-2 ⁽¹⁾ SW1DS1-1 ⁽²⁾	18	GRN	CHASSIS GND	CHASSIS GND	NA		
W3	P1-3	SW1-2	18	BLK	SWITCHED 12V	AUGER ON/OFF	BUTTON IN/OUT		
W5	P1-4	SW2-1	18	YEL	SWITCHED 12V	PIVOT DOWN	STICK LEFT		
W6	P1-5	SW2-3	18	ORG	SWITCHED 12V	PIVOT UP	STICK RIGHT		
W8	P1-6	SW2-4	18	BLU	SWITCHED 12V	SPOUT UP	STICK UP		
W7	P1-7	SW2-2	18	BRN	SWITCHED 12V	SPOUT DOWN	STICK DOWN		
NC	P1-8				114017 PLUG	NC	NA		
W10	P1-9	SW4-2	18	VIO	SWITCHED 12V	FLOW GATE CLOSE	BOT TRIGGER		
W9	P1-10	SW3-2	18	WHT	SWITCHED 12V	FLOW GATE OPEN	TOP TRIGGER		
NC	P1-11				114017 PLUG	NC	NA		
NC	P1-12				114017 PLUG	NC	NA		
¹ DS1 R	¹ DS1 Requires a 2400Ω series dropping resistor (R1).								
² SW1D	² SW1DS1 Requires a 220Ω								

	MFG	P/N
DS1	BIVAR	PM3GD12V
SW2	ΟΤΤΟ	T4-CJ2212
SW1	APEM	IPR1SAD3LOG



WIRING DIAGRAM

Additional auxiliary work lights are available from Kinze Repair Parts which may be wired into existing auxiliary light wires in the harness. The vertical auger work light is wired into the black terminal connector.

Grain cart safety/warning lights are the LED type and meet ASAE standards. Check with tractor manufacturer for correct wiring harness to be wired into lights on your tractor.



Auxiliary Light



Auxiliary Light Harness Storage Location





ELECTRONIC SCALE

The major elements of the electronic scale are the indicator, two 50,000 lb. rated compression type load cells at the rear of the axle assembly (applicable to track and flotation type carts) and four spindle type weigh axles (applicable to row crop carts), 3³/₄" hitch weigh beam, the junction box (j-box) and the battery power cable.

For additional information see "Electronic Scale Troubleshooting" for step-by-step procedures for troubleshooting failures that may be encountered with the electronic scale.





CONTROL CABLE EXTENSION (P/N: A16354)



SIGNAL	RECEPT	GAUGE	COLOR	PLUG
POWER (12VDC)	1	14	RED	1
GROUND	2	14	GREEN	2
AUGER ON	3	16	BLACK	3
AUGER OFF	8	16	VIOLET	8
PIVOT DOWN	4	16	YELLOW	4
PIVOT UP	5	16	ORANGE	5
SPOUT DOWN	7	16	BROWN	7
SPOUT UP	6	16	BLUE	6
FLOW GATE OPEN	10	16	WHITE	10
FLOW GATE CLOSE	9	16	GRAY	9

SCALE HARNESS EXTENSION CABLE (P/N: 10565201)



	WIRE HOOK UP CHART							
REF DES	FROM	USE W/	TO	USE W/	GAUGE	COLOR	FUNCTION	
W1	X1-1	3	X2-1	4	18	RED	PWR	
W2	X1-2	3	X2-2	4	18	BLACK	GND	
W3	X1-3	3	X2-3	4	18	BLUE	ANALOG	
W4	X1-4	3	X2-4	4	18	GREEN	ANALOG	

JUNCTION BOX 30' CABLE (P/N: R1431)



