



Connecting to Case IH FieldOps™


Blue Vantage 8.08.00.0837 - Blue Connect 8.08.00.1115

Sign in to Kinze Blue Connect by clicking on the link below.


<https://connected.kinze.com/>

A screenshot of the 'Sign In' page on the Kinze Blue Connect website. The page has a white background. At the top center, the text 'Sign In' is displayed in a bold, dark font. Below this, there are two input fields: 'Email' and 'Password'. The 'Password' field includes a 'Show' button with an eye icon. A blue 'Sign in' button is centered below the input fields. At the bottom left, there is a 'Sign up' link, and at the bottom right, there is a 'Forgot password' link.


Select Settings and click Connections.




Select Case IH FieldOps™ and click Connect.



Login to Case IH FieldOps™. Ensure all the requested permissions are checked and click Accept.




Check to make sure Case IH FieldOps™ is connected. Green checks indicate everything is configured correctly. Growers, farms, fields, and products will be downloaded to connected Kinze Blue Vantage displays.




Connect your Blue Vantage display to a Wi-Fi network with internet access and login to your Blue Connect account using the Account Configure button.


Note: Your Blue Vantage display does not need to be connected to a planter to complete these steps.



Verify that you are connected to a Wi-Fi network, and a network name is shown. Turn on Map Sync to allow download of data to Blue Connect and Case IH FieldOps™.



Verify that your Blue Connect status is good from the Blue Vantage Health screen. Click on Health and Blue Connect.



Case IH FieldOps™ Data Transfer

Active FieldOps™ Growers, Farms, Fields, and Products will be synced to connected Kinze Blue Vantage displays each time a map sync operation is performed. **Blue Vantage Map Sync must be enabled.**